CERIO Corporation

ANT-15AQ

5GHz 4x4 Outdoor IP68 Wide Rang Directional 15dBi Panel Pole/Wall Mount Antenna Installation Guide



Technical Support


E-mail: <u>support@cerio.com.tw</u> TEL: +886-2-8911-6160 #222 Web Site: <u>www.cerio.com.tw</u>

Package Contents :

ANT-15AQ Main Unit x1
Adjustable Pole & Wall Mounting Kit (OW-PKUR) x1
Quick Installation Guide x1
Warranty Card x1

Main Unit Overview : (ANT-15AQ)





Real / with OW-PKUR


Real


Installation:

Mount the antenna on the brackets according to the Mounting diagram. Make sure the ANT-15AQ antenna polarization parallel direction you needed. When the antenna polarization are vertical to the ground, the antenna is vertical polarized. When the antenna polarization are horizontal to the ground, the antenna is horizontal polarization.


1. ANT-15AQ design in a **horizontally- antenna**, Mount the ANT-15AQ antenna on the antenna

on the mast supplied by customer according to the Mounting diagram. Make sure that when ANT-15AQ is installed as standard, the antenna points horizontally, the Horizontal beam width is 35°, and the Vertical beam width is 65°; or when the ANT-15AQ casing is rotated 90 degrees, the antenna points horizontally, and the Horizontal beam width is 65°, Vertical beam width is 35°






2. Test the antenna with the device to make sure it is receiving the best RSSI signal: turn the azimuth and elevation, then tighten all the screws and make sure your own RF cable is connected with a lock seal, if you bought the LLMR-NNP-1M/ 2M RF cable, you can directly use the waterproof cap provided with LLMR-NNP-1M/2M to tightly seal the connector between ANT-15AQ RF cables.



The RF Cables to Outdoor AP Device By Optional

1. Pole Mount (Pole Range: Ø30-Ø90mm)



2. Alternative wall mount

Drill 4 holes on the wall with following dimensions.

Tilt angle adjustable by pole mount

(Based on the panel antenna by side view)

