

# CERIO Corporation

## DR-4000

### Multi WAN Gigabit VPN Gateway



## User's Manual

### Default IP / Login Information

IP Address	192.168.2.1
User Name	root
Password	default

<b>1.</b>	<b>Device and Software Configuration</b> .....	<b>5</b>
<b>1.1</b>	<b>Device appearance</b> .....	<b>5</b>
<b>1.2</b>	<b>Setup Preparation of Device</b> .....	<b>6</b>
<b>1.3</b>	<b>Login Web Page</b> .....	<b>8</b>
<b>2.</b>	<b>Operating Mode Introduction</b> .....	<b>10</b>
<b>2.1</b>	<b>Router Mode</b> .....	<b>10</b>
<b>2.2</b>	<b>Captive Portal Mode</b> .....	<b>10</b>
<b>3.</b>	<b>System Configuration</b> .....	<b>11</b>
<b>3.1</b>	<b>WAN Setup</b> .....	<b>11</b>
<b>3.2</b>	<b>WAN Traffic Setup</b> .....	<b>14</b>
<b>3.3</b>	<b>VLAN Setup</b> .....	<b>15</b>
<b>3.3.1</b>	<b>Network Button</b> .....	<b>16</b>
<b>3.3.2</b>	<b>Pull-down menu @ Bandwidth Control</b> .....	<b>16</b>
<b>3.3.3</b>	<b>Pull-down menu @ DHCP Server</b> .....	<b>17</b>
<b>3.4</b>	<b>Authentication(Hotspot Setup)</b> .....	<b>20</b>
#	<b>Authentication Button:</b> .....	<b>21</b>
#	<b>Authentication Dropdown Button</b> .....	<b>22</b>
<b>3.4.1</b>	<b>Guest</b> .....	<b>23</b>
<b>3.4.2</b>	<b>Local User</b> .....	<b>24</b>
<b>3.4.3</b>	<b>OAuth2.0</b> .....	<b>24</b>
<input type="checkbox"/>	<b># Sample for Google OAuth2.0 setup</b> .....	<b>24</b>
<input type="checkbox"/>	<b># Sample for Facebook OAuth2.0 setup</b> .....	<b>27</b>
<b>3.4.4</b>	<b>POP3 Server</b> .....	<b>31</b>
<b>3.4.5</b>	<b>Customize Page</b> .....	<b>31</b>
<b>3.4.6</b>	<b>Language</b> .....	<b>33</b>
<b>3.4.7</b>	<b>Walled Garden</b> .....	<b>33</b>
<b>3.4.8</b>	<b>Privilege Address</b> .....	<b>34</b>
<b>3.4.9</b>	<b>Profile</b> .....	<b>34</b>
<b>3.5</b>	<b>High Availability</b> .....	<b>35</b>
<b>3.6</b>	<b>VPN Server Setup</b> .....	<b>37</b>
<b>3.7</b>	<b>VPN Peer Setup</b> .....	<b>39</b>
<b>3.8</b>	<b>PPTP Server Setup</b> .....	<b>40</b>

3.9	L2TP Server Setup .....	42
3.10	PPTP/L2TP Account Setup .....	43
3.11	PPTP/L2TP Client Setup .....	44
3.12	IPSec Setup.....	46
3.13	Management.....	49
3.14	Time Server .....	54
3.15	SNMP .....	56
3.16	DDNS .....	57
3.17	Log Server Setup .....	58
3.18	Notification Setup.....	61
4.	Account .....	64
4.1	RADIUS Server.....	64
4.2	Remote LDAP Setup.....	64
4.3	Package Setup .....	66
4.4	Create An Account .....	68
4.5	Search Account .....	69
4.6	Pregenerated Tickets DB.....	70
4.7	Thermal Printer Setup .....	73
4.8	History Log .....	76
4.9	Online Log .....	76
4.10	Database Maintenance.....	77
5.	Advance.....	77
5.1	IP Filter .....	77
5.2	IP Group .....	80
5.3	Port Group.....	81
5.4	MAC Filter .....	82
5.5	Virtual Server .....	82
5.6	Access Control.....	83
5.7	IP Routing Setup.....	85

5.8	IP Routing Rule Setup .....	87
5.9	Time Policy .....	88
6.	Utility.....	89
6.1	Profile Setting.....	89
6.2	System Upgrade .....	90
6.3	Network Utility .....	92
6.4	Log Maintenance .....	93
6.5	Reboot.....	94
7.	Status.....	95
7.1	Overview .....	95
7.2	Local System Log .....	95
7.3	Session Log.....	96
7.4	Authentication Log .....	98
7.5	Remote System Log.....	99
8.	Technical documents .....	101
8.1	Example for PPTP/L2TP setup .....	101
8.2	Hotspot function used POS system application.....	104
	Login management interface for SP-800.....	105
	Install normal thermal printer .....	106
	Install QR Code thermal printer .....	107
	Set web authentication steps for POS system.....	110

# 1. Device and Software Configuration

## 1.1 Device appearance



1. DC Jack Power interface (Power input- interface-1 )

2. LED status indicator:

	<p><b>PWR LED:</b> When it is confirmed that the PoE input or DC input power is powered on, this LED is always on when the power is turned on.</p>
	<p><b>Fail LED :</b> System problem warning LED ,Operating system storage data cannot be accessed , (The light is always on when there is a fault).</p>
	<p><b>Online LED :</b> Online working LED , It flashes during the system startup process, and stays on after the system startup is successful and confirmed, (Indicating that the Ready state is successful).</p>
	<p><b>Ethernet port LED :</b> Link/Act connection LED from ETH1 port to ETH4 port</p>


3. **Reset button** (to restore the factory default, please press it for about 10-15 seconds. The Online LED and Fail LED will flash at the same time, indicating confirmation. You can release the button and wait for the system to return to the factory default).
4. **Gigabit / ETH1 (POE) Ethernet port**, The WAN or LAN port can be changed through software configuration **(Power input- interface-2 )**.
5. **Gigabit / ETH2 (POE) Ethernet port**, The WAN or LAN port can be changed through software configuration **(Power input- interface-3)**.
6. **Gigabit / ETH3 Ethernet port**, The WAN or LAN port can be changed through software configuration.
7. **Gigabit / ETH4 Ethernet port**, the WAN or LAN port can be changed through software configuration.
8. **GND ground screw pad** , The contact point for the housing ground screw of this device.

## 1.2 Setup Preparation of Device


Please PC link to Device used cat5/6 Ethernet cable.

[The following setup uses a Windows PC, user OS may vary.](#)


**Step 1:** Please click on the computer icon in the bottom right window, and click “Open Network and Internet settings”



**Step 2:** After click left side "Ethernet" function, click on the right side “Change adapter options” again.



**Step 3:** In “Change adapter options” Page. Please find Ethernet (Local LAN) and Click the right button on the mouse and Click “Properties”





**Step 4:** In Properties page to setting IP address, please find “Internet Protocol Version 4 (TCP/IPv4)” and double click or click “OK” button.

**Step 5 :** Select “Use the following IP address”, and fix in IP Address : 192.168.2.#

ex. The # is any number by 1 to 253

Subnet mask : 255.255.255.0



And Click "OK" to complete the fixed computer IP setting

## 1.3 Login Web Page

DR-4000 supports web-based configuration. Upon the completion of hardware installation, DR-4000 can be configured through a PC/NB by using its web browser such as Internet Explorer 6.0 or later version or similar browser.


- **Default IP Address:** 192.168.2.1
- **Default Subnet Mask:** 255.255.255.0
- **Default Username and Password**

<b>MODE</b>	Router mode
<b>Management Account</b>	Root Account
<b>Username</b>	root
<b>Password</b>	default


**Notice** Please note that the LAN IP addresses in each mode are different from each other and will not continue. For the first time after switching modes, always perform access management on the LAN default IP address of 192.168.2.1

## Launch Web Browser

Open IE browser or other browsers such as Firefox, Chrome, and Edge, and enter the device default IP address in the URL address bar: <http://192.168.2.1> to open the WEB management interface.



Please use default Users name: **“root”** and default password **“default”** to login.




## 2. Operating Mode Introduction


### 2.1 Router Mode

When administrator select use Route mode then system can set 1WAN 3LAN Router also can select 1LAN 3WAN and 2WAN/2LANoutbound load balancer.

This Router mode support IP Routing setup/Firewall/HA/VPN/Multi-WAN/QoS enforcement and Built-in AAA Radius server



### 2.2 Captive Portal Mode



If the environment already has a router or firewall device, administrator demand is only to add the new page hotspot function, this time can be switched to Captive Portal mode and connected in parallel to the router or firewall equipment can be completed (The mode is no Router NAT function in this mode).


(The default IP of this mode is also 192.168.2.1, but it is not designed to be linked to the IP location of Router mode. When switching to this mode, please make sure that the IP network segment of the connected computer is also the same as 192.168.2.X. You have successfully entered this mode. model)

## 3. System Configuration


CERIO's **DR-4000** is multifunctional authentication Gateway, support multi-WAN outbound load balance. The **DR-4000** Built-in hardware independent VPN engine administrator can build a secure tunnel in the network environment and support High Availability can make sure that the network is working normally.

### 3.1 WAN Setup

Administrator can set one WAN or multi-WAN load balance in the WAN Setup function. Please click System → WAN Setup




#### WAN Port Setup



- **WAN Port:** Administrator can select 1WAN/3LAN or 1LAN/3WAN or 2WAN+/2LAN, the default is 1WAN/3LAN Port.

**Physical Ethernet Ports Settings Detailed list of different WAN and LAN ports:**



Ethernet Speed		1Gb	1Gb	1Gb	1Gb
Mode / Port		ETH1	ETH2	ETH3	ETH4
1	1WAN(1Gb)/3WAN(1Gb+1Gb+1Gb) / WLL	WAN	LAN	LAN	LAN
2	1LAN(1Gb)/3WAN(1Gb+1Gb+1Gb) / LWWW	LAN	WAN	WAN	WAN
3	2WAN(1Gb+1Gb)/2LAN(1Gb) / WWLL	WAN	WAN	LAN	LAN

- **WAN List** : When selecting Multi-WAN, the WAN Priority setting will be displayed. Please click the Save button and the system will display the list of Multi-WAN.

WAN List			
#	Active	Mode	Edit
0	<input checked="" type="checkbox"/>	Dynamio IP	<input type="button" value="Edit"/>
1	<input checked="" type="checkbox"/>	Dynamio IP	<input type="button" value="Edit"/>
2	<input checked="" type="checkbox"/>	Dynamio IP	<input type="button" value="Edit"/>



When selecting 2WAN up , you can set the load balancing priority setting on the WAN traffic setting function page.

- **WAN Priority** : The system will first determine the priority of 3WAN,The smaller the value, the higher the priority. If setting to 1/1/2, it is WAN0/WAN1 Load Balance, and WAN2 is used as Backup function. If it is setting to 1/1, it is WAN0/WAN1 Load Balance. If it is setting to 1/2, WAN2 is used as Backup function..

**WAN Priority**

WAN0 Priority

WAN1 Priority

WAN2 Priority

- **Primary Port:** If set 2 WAN or 3WAN function, administrator must select one primary for WAN Port, The WAN Port "primary port" setting, which mainly allows the system to use through the set WAN port, such as "system time" or DNS access, etc. If there is no special application, Please set to the default value "WAN0 ".
- **NAT Engine:** If enable the function then NAT will up performance, but firewall and routing rule of **DR-4000** will auto disable.
-

## WAN List

Administrator can set four connection types for the WAN port: Static IP, Dynamic IP, PPPoE and PPTP, at the same time can also Enable or Disable for NAT or DMZ functions.

Please click Edit button in WAN List.

#	Active	Mode	Edit
0	<input checked="" type="checkbox"/>	PPPoE	<input type="button" value="Edit"/>
1	<input checked="" type="checkbox"/>	Dynamio IP	<input type="button" value="Edit"/>
2	<input checked="" type="checkbox"/>	Dynamio IP	<input type="button" value="Edit"/>

➤ **Edit:** Administrator can set WAN function.

The image shows several configuration panels:

- WAN Setup:** WAN  Enable  Disable
- WAN Settings:** Mode: PPPoE
- PPPoE:** User Name: 73137845@hinet.net, Password: [masked], MTU: 1492, Reconnect Mode: Always On
- NAT:** NAT  Enable  Disable
- DMZ Setup:** Mode: Disable
- MAC Clone:** Mode: Default MAC Address

- **WAN Setup:** Administrator can set Enable or Disable for the WAN Port function.
- **WAN Settings:** Administrator can select Static IP, Dynamic IP, PPPoE and PPTP type of the WAN Port.
- **MAC Clone:** The MAC address is a 12-digit HEX code uniquely assigned to hardware as identification. Some ISPs require you to register a MAC address in order to access to Internet. If not, you could use default MAC or clone MAC from a PC.
- **NAT:** Administrator can set Enable or Disable the NAT function. If Disable NAT function administrator must manual to set routing.
- **DMZ:** DMZ is a physical or logical sub-network that separates an internal local area network (LAN) from other untrusted networks, usually the Internet. External-facing

servers, resources and services are located in the DMZ so they are accessible from the Internet but the rest of the internal LAN remains unreachable. This provides an additional layer of security to the LAN as it restricts the ability of hackers to directly access internal servers and data via the Internet.

## 3.2 WAN Traffic Setup

WAN Traffic setup function improves the distribution of workloads across multiple computing resources. WAN Traffic function aims to optimize network resource use maximize throughput or minimize response time and avoid overload of any single WAN port resource.

If administrator set multi-WAN configuration, administrator can assign weights or speed weights to WAN in the "**WAN traffic setup**" function to indicate the percentage of traffic that should be sent to each WAN.



- **Mode:** If set multi-WAN, administrator can select Load Balance by Assign Weight or Line Speed Weight.
  - **Assign Weight:** The WAN Assign Weight function can setup handle more requests and handle fewer requests. Assigning weights to WAN allows the **DR-4000** appliance to determine how much traffic each load balanced server can handle, and therefore more effectively balance load. The Weight set Max=10 unit.



- **Line Speed Weight:** The function requires administrator to definitely specify the real upload and download line speed of each WAN interface, the system will calculates the maximum bandwidth for all WAN interfaces and then the flow distribution.

☰ Line Speed Weight

WAN0 (U/D)kbps	<input type="text" value="1024000"/>	<input type="text" value="1024000"/>
WAN1 (U/D)kbps	<input type="text" value="1024000"/>	<input type="text" value="1024000"/>
WAN2 (U/D)kbps	<input type="text" value="1024000"/>	<input type="text" value="1024000"/>

- **Connection Detect:** Enable connection detection, set the target IP of the specified Ping, and set the interval period of each Ping in "seconds". Set the Failure Count after the number of failures to truly enable WAN load balancing .

☰ Connection Detect

Service  Enable  Disable

IP Address to Ping

Ping Interval  Second

Failure Count

### 3.3 VLAN Setup

The default Router mode supports 16 groups of virtual network services. By default, each virtual network supports the 802.1Q Tag VLAN function. The administrator only needs to click Enable, and the system will be able to complete the setting of 802.1Q Tag VLAN.


☰ VLAN List

#	VLAN Mode	Flag	IP Address	Netmask	Action
0	<input checked="" type="checkbox"/>	Native	192.168.2.1	255.255.255.0	Network
1	<input type="checkbox"/>	VLAN TAG: 101	192.168.101.254	255.255.255.0	Network
2	<input type="checkbox"/>	VLAN TAG: 102	192.168.102.254	255.255.255.0	Network
3	<input type="checkbox"/>	VLAN TAG: 103	192.168.103.254	255.255.255.0	Network
4	<input type="checkbox"/>	VLAN TAG: 104	192.168.104.254	255.255.255.0	Network
5	<input type="checkbox"/>	VLAN TAG: 105	192.168.105.254	255.255.255.0	Network
6	<input type="checkbox"/>	VLAN TAG: 106	192.168.106.254	255.255.255.0	Network
7	<input type="checkbox"/>	VLAN TAG: 107	192.168.107.254	255.255.255.0	Network

- **VLAN Mode** : Display on/off for the VLAN network.
- **Flag** : Display master VLAN and VLAN Tag No. information.
- **IP Address** : Display IP Address for VLAN Network.
- **NetMask** : Display IP netmask.
- **Action** : click button to set VLAN network functions , click Pull-down menu to " Bandwidth Control" and "DHCP Server".

### 3.3.1 Network Button

Administrator can click  button to set VLAN network functions.



The screenshot shows the 'VLAN Setup' configuration page. It is divided into three sections: 'VLAN Setup', 'IP Setup', and 'VLAN Tag Setup'.  
1. **VLAN Setup**: Contains 'VLAN Mode' with radio buttons for 'Enable' (selected) and 'Disable'.  
2. **IP Setup**: Contains 'IP Address' (192.168.2.1) and 'Netmask' (255.255.255.0) input fields.  
3. **VLAN Tag Setup**: Contains a 'VLAN TAG' checkbox (unchecked) and a text input field with '1-4093'.


- ✓ **VLAN Mode** : Administrator can select Enable or disable for the VLAN Network.
- ✓ **IP Mode** : Administrator can select enable or disable function for VLAN IP.
- ✓ **IP Address/ NetMask** : Administrator can set IP address and netmask for the VLAN.



VLAN services and IP addresses must have at least one set of VLAN services. **Do not turn off the default set of virtual network service (VLAN) functions (equal to no LAN state), which will cause the need to return to the default values. Need to re-setting again for the device.**

### 3.3.2 Pull-down menu @ Bandwidth Control

Administrators can set bandwidth limit the max/min bandwidth of the Wi-Fi users, Bandwidth control can set IP/MASK , IP Range, Port(Service), SIP, RTP/RTSP and WEB.



**Bandwidth Control**

Mode  Enable  Disable

Session Limit Per IP

---

**Total Bandwidth Control**

Mode  Enable  Disable

Upload  Kbps

Download  Kbps


- **Mode : IP:** Administrators can choose to enable or disable bandwidth control function.
- **Session Limit Per IP:** Session limit by all IP address, The default value is to limit the use of each user IP to 1024 Sessions
- **Total Bandwidth Control:** UP/Download bandwidth limit by VLAN
- **OoS Rule List:** Administrator can set IP/MASK , IP Range, Port(Service), SIP, RTP/RTSP and WEB to management bandwidth, Max can set 10 rule.


#	Active	Rule Mode	Value1	Value2	Upload(Kbps)	Download(Kbps)	Comment
1	<input checked="" type="checkbox"/>	ANY			1024	1024	
2	<input type="checkbox"/>	IP/Mask			1024	1024	
3	<input type="checkbox"/>	IP Range			1024	1024	
4	<input type="checkbox"/>	Port			1024	1024	
5	<input type="checkbox"/>	SIP			1024	1024	
		RTSP			1024	1024	
		RTP			1024	1024	
		WEB			1024	1024	

- **Any:** Bandwidth control by any protocol.
- **IP/MASK:** Bandwidth control by a subnet.
- **IP Range:** Bandwidth control by IP range.
- **Port:** Bandwidth control by port (service), ex. FTP port (20,21)
- **SIP:** Bandwidth control by Session Initiation Protocol.
- **RTSP/RTP:** Bandwidth control by Streaming.
- **WEB:** Bandwidth control by web protocol.


### 3.3.3 Pull-down menu @ DHCP Server

Administrator can set DHCP function. Please click **Network** pull-down button to set DHCP Server.






- ✓ **Mode:** Administrator can select enable / disable the function
- ✓ **DHCP Relay :** Administrator can select enable / disable the function



- **Server Interface :** For this function, you can choose to have DHCP Relay follow the interface, you can choose the enabled WAN0~2 interface, or choose the DHCP settings of other VLAN interfaces VLAN1~VLAN15.
- ✓ **Start IP:** Set Start IP for DHCP Service.
- ✓ **End IP:** Set End IP for DHCP Service.

- ✓ **Netmask: Set IP Netmask, the default is 255.255.255.0**
- ✓ **Gateway: Set Gateway IP for DHCP Service.**
- ✓ **DNS (1-2) IP:** Set DNS IP for DHCP Service.
- ✓ **WINS IP:** Enter IP address of the Windows Internet Name Service (WINS) server; this is optional.
- ✓ **Domain:** Enter the domain name for this network.
- ✓ **Lease Time:** The IP addresses given out by the DHCP server will only be valid for the duration specified by the lease time. Increasing the time ensure client operation without interruptions, but could introduce potential conflicts. Lowering the lease time will avoid potential address conflicts, but might cause more interruptions to the client while it will acquire new IP addresses from the DHCP server. Default is **86400** seconds



The screenshot displays two sections of a web interface. The top section, titled "DHCP Client List", contains a table with the following data:

#	IP Address	MAC Address	Hostname	Expired	Action
1	192.168.2.10	08:00:20:08:00:08	192.168.2.10	20:0:43	Fixed
2	192.168.2.12	08:00:20:08:00:08		18:48:16	Fixed

The bottom section, titled "Static Lease IP Setup", includes three input fields: "Comment", "IP Address", and "MAC Address". An "Add" button is located to the right of the "MAC Address" field.

Below the setup section is a "Static Lease IP List" table with the following data:


#	Comment	IP Address	MAC Address	Action
-	-	-	-	-

- **DHCP Client List:** Administrator can view IP address used status of client users on each DHCP Server.
- **Static Lease IP Setup:** Administrator can set be delivered fixed IP address to the users. (This MAC Address binding IP address function can bind up to 100 sets of settings).

## 3.4 Authentication(Hotspot Setup)

The function is for hotspot Authentication. It supports authentication for local users / RADIUS Server / OAuth2.0 and Guest. RADIUS Server authentication support PoP3 / LDAP(AD) and Package.

Please click on **System -> Authentication**




VLAN List			
#	VLAN Mode	Authentication	Action
0	On	Off	Authentication
1	Off	Off	Authentication
2	Off	Off	Authentication
3	Off	Off	Authentication
4	Off	Off	Authentication
5	Off	Off	Authentication
6	Off	Off	Authentication
7	Off	Off	Authentication

- # : Display 8 VLANs list of Authentication.
- **VLAN Mode** : Displays VLAN on/off status.
- **Authentication** : Displays VLAN# whether enable or disable web authentication.
- **Action** : The function has 2 buttons (Authentication and Dropdown)

## # Authentication Button:

 : By clicking the Authentication button, administrator can enable or disable this function.




The screenshot displays a web management interface with three main sections:

- Authentication:** Features a toggle switch set to "Enable" (radio button selected).
- Authentication Setup:** Includes fields for "Multiple Login" (checkbox), "Login Timeout" (10 Minutes), "Redirect URL" (http://www.google.com), and "Login URL" (domain0.login). It also has "Authentication Log" and "Session Log" toggles, both set to "Disable".
- Local User Setup:** Features a toggle switch set to "Disable" (radio button selected) and a "Display Name" field containing "Local User".
- Radius Setup:** Features a toggle switch set to "Disable" (radio button selected) and a "Display Name" field containing "Radius User".

- **Authentication** : Administrator can enable or disable authentication function.
- **Multiple Login** : Administrator can set one account to multiple users simultaneously login and the users can set limit.( 0 = not limited)
- **Login Timeout** : After account login for some time no traffic, system will automatic timeout for account. Administrator can enter a time(Minutes).
- **Redirect URL** : After the success of the login, system will redirect to URL. Administrator can enter web site URL.
- **Login URL** : Administrator can set URL for login page. Set the URL that automatically triggers the login page. When you start the web page and want to log in, directly enter the default login page URL <http://domain0.login>, and you can quickly jump to the complete login authentication login page <http://domain0.login/login/index.cgi> , if you want to use <https://domain0.login>, please be sure to confirm whether HTTPS login is enabled and open for use in the "Management Interface Login Settings". Please refer to 3.13 System Management → "Login Methods" Settings, or as shown below.

Login Methods

HTTP	<input checked="" type="checkbox"/>	80	Port
HTTPS	<input checked="" type="checkbox"/>	443	Port
Telnet	<input checked="" type="checkbox"/>	23	Port
SSH	<input type="checkbox"/>	22	Port




- **Authentication Log:** Account authentication log will copy to the device 's syslog server.
- **Session Log :** If network have Syslog server. Administrator can to system → management setting IP address for syslog server and enable the function. Account session log will copy to the device 's syslog server.
- **Local User :** Administrator can enable authentication for local user. Create user account can to reference “3.4.2 Local User”.
- **RADIUS :** Authentication support remote RADIUS Server. Administrator can enter security information for remote RADIUS Server.

## # Authentication Dropdown Button



: By Clicking the Dropdown button, Administrators can set authentication functions.




## 3.4.1 Guest

Administrator can enable or disable guest authentication. If enabled, the administrator can set guest Count Limit / login time and type and flow control.

- **Service** : Administrator can select enable or disable this function.
- **Login Type** :
  - **One Time**: Login to start counting until the end of time.
  - **Multiple Times**: logout time will stop counting until the next re-login to time start counting.
- **Count Limit**: Administrator can set guest limit.
- **Login Time**: Within a certain timeframe with no traffic, the system will auto logout. (The default is 10 minutes, you can fill in 0-720 minutes and 0 is unlimited).
- **QoS**: Administrator can restrict the traffic of guest. Traffic management can set users upload and download traffic.

## 3.4.2 Local User

Administrator can create local user account for web login.




#	Name	Action
1	oerio	Delete
2	danny	Delete

- **User Name** : Administrator can create users account.
- **Password** : Set account password.

## 3.4.3 OAuth2.0

The OAuth2.0 function supports Facebook and Google by default. Users can add additional OAuth2.0 servers through UI settings.



#	Active	Provider	Action
1	Off	Google	Edit
2	Off	Facebook	Edit


- **#** : Display items.
- **Active** : Display on/off status for the authentication.
- **Provider** : Display authentication server. The system default use authentication server for Google and Facebook

### ➔ # Sample for Google OAuth2.0 setup

Please complete the application on the Google website to receive an account ID and password, follow the steps below.

**Step.1** Please go to the **Google Developers Console page** and **create a project**

(Reference <https://developers.google.com/identity/protocols/OAuth2>)



**New Project**

Project name <sup>?</sup>


CERIO-AAP-login

Your project ID will be cerio-aap-login <sup>?</sup> [Edit](#)

[Show advanced options...](#)

[Create](#) [Cancel](#)

**Step.2** Click Credentials to create OAuth client ID in the API manager page.



**API** API Manager

Overview

**Credentials**

**API key**  
Identifies your project using a simple API key to check quota and access.  
For APIs like Google Translate.


**OAuth client ID**  
Requests user consent so your app can access the user's data.  
For APIs like Google Calendar.

**Service account key**  
Enables server-to-server, app-level authentication using robot accounts.  
For use with Google Cloud APIs.

**Help me choose**  
Asks a few questions to help you decide which type of credential to use.

[Create credentials](#)

**Step.3** Select web application in the “Application Type” section and set “Restrictions” URL.



Create client ID

**Application type**

Web application

Android [Learn more](#)

Chrome App [Learn more](#)

iOS [Learn more](#)

PlayStation 4

Other

[Create](#) [Cancel](#)

**Name**

Web client 1

**Restrictions**

Enter JavaScript origins, redirect URIs, or both

**Authorized JavaScript origins**

For use with requests from a browser. This is the origin URI of the client application. It can't contain a wildcard (http://\*.example.com) or a path (http://example.com/subdir). If you're using a nonstandard port, you must include it in the origin URI.

http://www.example.com

**Authorized redirect URIs**


For use with requests from a web server. This is the path in your application that users are redirected to after they have authenticated with Google. The path will be appended with the authorization code for access. Must have a protocol. Cannot contain URL fragments or relative paths. Cannot be a public IP address.

http://www.example.com/oauth2callback

**Step.4** Set Authorized JavaScript origins and Authorized redirect URLs (**important**)

Administrator must set login URL in the device function. After complete set of login URL go to the “**Restrictions**” function in web page. Follow the steps below to set login URLs

- Setup login URL in the device. Please Click **system**➔**Authentication** and enable the function.
- The “Authentication Setup” page to set Login URL



After complete set of login URL go to the “**Restrictions**” function in web page. Copy and paste the login URL from the system display into the “Restriction” page on the Google Developer website.

- Google Authorized JavaScript origins URL is **http://domain0.login.com** (same as Login URL)
- Google Authorized redirect URLs is **http://domain0.login.com/login/callback.cgi**

### Authorized JavaScript origins

For use with requests from a browser. This is the origin URI of the client application. It can't contain a wildcard (http://\*.example.com) or a path (http://example.com/subdir). If you're using a nonstandard port, you must include it in the origin URI.

### Authorized redirect URIs

For use with requests from a web server. This is the path in your application that users are redirected to after they have authenticated with Google. The path will be appended with the authorization code for access. Must have a protocol. Cannot contain URL fragments or relative paths. Cannot be a public IP address.

**Step.5** After completing the “Restrictions” setup, click the create button. An OAuth Client page will pop-up with your “client ID” and “client secret”. Administrators must copy and paste their client ID and secret into the OAuth 2.0 Setup page in our software UI.

OAuth client

Here is your client ID

Here is your client secret

OK

OAuth 2.0 Setup Advanced

Client ID


Client Secret

Save and reboot the AP system, complete the setup.


## ➔ # Sample for Facebook OAuth2.0 setup

Please complete the application on the Facebook website to receive an account ID and password, follow the steps below.

**Step.1** Please to Facebook developer’s page and add a New App



**Step.2** Select WWW function



**Step.3** Administrator must set www for your information.

**Create a New App ID**  
Get started integrating Facebook into your app or website

**Display Name**


**Namespace**

**Contact Email**


**Category**

By proceeding, you agree to the [Facebook Platform Policies](#)

**Step.4** Please click "Setting" and add Platform



### Step.5 Select Platform for “Website”




### Step.6 Enter URL is <http://domain0.login.com/login/callback.cgi>

Site URL

<http://domain0.login.com/login/callback.cgi>

Administrator must set login URL in the device function. After complete set of login URL go to the “Facebook Site URL” function in web page. Follow the steps below to set login URLs

- Setup login URL in the device. Please Click **system** → **Authentication** and enable the function.
- The “**Authentication Setup**” page to set Login URL



Authentication Setup

Multiple Login  3 User(s)

Login Timeout 10 Minutes


Redireot URL http://www.google.com

Login URL domain0.login.com

Session Log  Enable  Disable

After complete set of login URL go to the “Facebook Site URL” function in web page. Copy and paste the login URL from the system display into the “Site URL” page on the Facebook website.

**Step.7** Click Advanced function to enable the “Native or desktop app?” and “Is App Secret embedded in the client?”



Settings


- Basic
- Advanced
- Roles
- Alerts

Basic | Advanced

Yes Native or desktop app? Enable if your app is a native or desktop app

Yes Is App Secret embedded In the client? This restricts the app secret usage to methods allowed by a client token [?]

**Step.8** After completing the “Facebook Site URL” setup. Administrators must copy and paste their App ID and App secret into the OAuth 2.0 Setup page in our software UI.



AAP\_TEST

This app is in development mode and can only be used by app admins, developers and testers [?]

API Version [?] v2.6

App ID [REDACTED]

App Secret [REDACTED]6 Reset




The screenshot shows the 'OAuth 2.0 Setup' form with an 'Advanced' button. It contains two input fields: 'Client ID' with a value ending in '9' and 'Client Secret' with a value ending in '26'.



Client ID and Client Secret setup by third parties such as Facebook and Google are subject to change. The instructions above follow the 2016 setup procedure. Any future changes to the Facebook/Google process may lead to our instructions becoming invalid.

### 3.4.4 POP3 Server

The purpose of this integrated function is to allow clients to link a POP3 server for receiving emails from a remote server.




The screenshot shows two forms side-by-side. The left form is 'POP3 Server' with a 'Service' section containing 'Enable' (selected) and 'Disable' radio buttons, and a 'POP3 Settings' section with fields for 'Display Name' (POP3 User), 'Host', 'Port' (25), and 'Connect Type' (None). The right form is 'POP3 Server Test' with 'EMAIL' and 'Password' input fields and a 'Test' button.

- **POP3 Server** : Click “Enable” or “Disable” to activate this function
- **Display Name** : Set the “Display Name” based on the appropriate POP3 user or client
- **Host** : Define the desired Host server name
- **Port** : Input the proper port number for the corresponding server
- **Connect Type** : Select the Connect type with options of “STARTTLS”, “SSL/TTL”, or “None”
- **POP3 Server Test** : Use this tool to test if the POP3 server is operating correctly with your selected email


### 3.4.5 Customize Page

This function is to customize the user Login Page. This supports Multiple Language and allows comprehensive customization through HTML editing.




## Page Setup

- **Template** : Administrator can select Enable or disable.
  - Select enable to active default Login Page



- Select disable to active HTML Source code window for customization



**Sample:** See sample login page below that is customized by html coding (*sample login page html code templates are available on Cerio website*)




Captive Portal Authentication Login Page for CenOS 5.0

The following function uses the enabled Template

- **Multiple Language** : Administrator can select enable or disable multiple language for login page. Administrator must to Language function create new language.
- **Page Color Setup** : Administrator can change the login page color.


### 3.4.6 Language

Administrator can create other language for login page.



### 3.4.7 Walled Garden

This function provides certain free services or advertisement web pages for users to access the websites listed before login and authentication. User without the network access right can still have a chance to experience the actual network service free of charge in Walled Garden URL list.



- **Display Name:** Set name of Website.
- **IP Address/Domain:** Set IP or Domain of the Open the website.
- **Full URL:** Set full website name.

### 3.4.8 Privilege Address


This function provides local device can access Internet without authentication. If there are some workstations belonging NGS Access Point that need to access to network without authentication, enter the IP or MAC address of these workstations in this list.



- **Device Name:** Enter Device or Users Name.
- **IP Address:** Enter used IP Address of Device or Users PC.
- **MAC Address:** Enter MAC Address of Device or Users PC.

### 3.4.9 Profile

Administrator can backup current authentication configuration and login page for HTML Source code. But also can recover.




Click **“Save”** button to save your changes. Then click **Reboot** button to activate your changes.

## 3.5 High Availability

When Gateway systems downtime working, the all network will can't normal work. If administrator set the high availability feature will be able to reduce the accidental interruption of the network and prevent against data loss.

CERIO **DR-4000** support system backup of the high availability function can mirror backup to many **DR-4000**.

Please click **“System”** → **“High Availability”** to set the function.



➤ **Service:** Administrator can select Enable or Disable the HA function.

### High Availability Setup

- **State:** Administrator can set HA type of the Master or Backup.
- **Virtual Router ID:** Administrator must set same virtual router ID in all the high availability devices
- **Priority:** Administrator can set the priority level.
- **Advert Interval:** After how many sec to the recovery.

**Virtual IP Setup:** Administrator can set HA function in different VLAN.

VLAN	Service	Virtual IP Address	Edit
0	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
1	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
2	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
3	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
4	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
6	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
6	<input type="checkbox"/> Off		<input type="button" value="Edit"/>
7	<input type="checkbox"/> Off		<input type="button" value="Edit"/>

**Service**  Enable  Disable

---


**Virtual IP Settings**

Virtual IP

Authentication Type  PASS  AH

Password

- **Virtual IP:** Administrator must set a Virtual IP address for HA device. (The following concepts)





- **Authentication Type:** Administrator can select PASS or AH type for HA security.
- **Password:** Administrator can set password for the HA security.

## 3.6 VPN Server Setup

**This VPN function support three protocol are VPN Server、PPTP/L2TP and IPsec, the VPN tunnel of these three types only select one VPN protocol to used it.**

Please click “System”→”VPN Server Setup” create VPN function.



VPN Service

Mode  Enable  Disable

### VPN Service

➤ **Mode:** Administrator can select Enable or Disable the VPA function.

VPN Server

Mode  Enable  Disable

---

VPN Settings

VPN Hostname: DR\_VPN

Bridge Mode:  Enable  Disable

DHCP filter:  Enable  Disable

Bridge VLAN: VLAN0

VPN IP Address: [Empty]

VPN Netmask: 255.255.255.0

VPN Port: 656

Encryption: AES

VPN Public Key

```
-----BEGIN RSA PUBLIC KEY-----
MIIBCgKCAQEAXyglrEaVRZxOkW3Yk6pt0A1rnjpayo0B896+JAbmpSJetGASqwx
/Pv72klolL0It0GjwqaECWDFwnjrU9g9M/mKCVy9c5HNnMJMSgQ3yga/REI4Tz40
bCjnMhmkWT7/ZqbOfNHy/KmzgatAS+YTOR18priDhl07KsQx0g3d9W3Md58mTbs
XCKhuCbtqahnxL05v1eEmXLOE8jTgBZ69Aiksk0SU43E6CIMkhG8GVswcSladpBk
7LGRRbK0ITWgkxHNayQZKsr3dzyzxdbKpC9IOZt1QRJBD4pVllITxbGAA3TKOZ1
supCAbKOxskW47UBsiHWR9rWgs15utA0XnwiDAQAB
-----END RSA PUBLIC KEY-----
```

Generate Public Key

Download Public Key

## VPN Settings

- **VPN Hostname:** Administrator can set a VPN host name. Each VPN host name can't be the same and can't have special symbols.
- **Bridge Mode:** Administrator can select bridge mode by VLAN or Manual.
- **DHCP filter:** You can choose to enable or disable it. When it is enabled, it can prevent the DHCP server IPs of the physical area network at both ends from sending IPs out of bounds. (You only need to enable this function unilaterally. If the DHCP filter is turned on at both ends, the network logic will be incorrect and the VPN cannot be successfully connected)
- **Bridge VLAN:** If bridge mode select VLAN, administrator can select set VLAN 0~7 for VPN bridge.
- **VPN IP Address/Netmask:** If bridge mode select manual, administrator must set an IP address/netmask for the VPN link and must set routing of LAN.



1. If administrator choose use bridge mode then VPN both sides beneath need use same class network.
2. If administrator choose use manual set IP address then must set IP routing of LAN

- **VPN Port:** Administrator can set Port for VPN.
- **Encryption:** Select VPN security of encryption type.

## VPN Public Key

**VPN Public Key**

```

-----BEGIN RSA PUBLIC KEY-----
MIIBCgKCAQEAvp+C8pLMuhpJAvosinha0xPMgSbpOLSPhkLR1VNT65N6hqMvGcjH
166MrHJDAXMEaTp0Q0geh5Zr2MRAQUYErICrXwMnS4wqDqsjYtnLsGPMLSaRN+W
PVUaJBcZKXP16vaYPI0wN4VYLEAto/op7G0Bm2a0NZjIh4j0tEJorua/k3jSUYa2
H80qQF/vhZ16XVYONueB019at1b5cMleQpuMLoqjrZ7kLto/447o+4UxMYu2m05W
6+PPRQa+Yo5ZkfwcmREzbR+PofKzPLJGWze3/IM9h++AoLXmhWlvAU2Y3bbg/G3n
/6QDfu7UP304QFj03eJNdsN6VBsh9+TtQIDAQAB
-----END RSA PUBLIC KEY-----
            
```

Generate Publio Key

Gen Key

Download Publio Key

Download

- **Generate Public Key:** Administrator can click the button to regenerate the VPN public key.
- **Download Public Key:** Administrator can click the button to download the VPN public key.



## 3.7 VPN Peer Setup



**When administrator set 3.6 VPN server is complete, this page must setup a real IP address and upload VPN key of the other end.**

Administrator can create new VPN connection for the VPN Peer.

Please click “System” → “VPN Peer Setup”



VPN Peer List						Create New Peer
#	Mode	Hostname	Description	WAN IP	Action	
-	-	-	-	-	-	-

**Create New Peer:** Administrator can click the button to create a VPN bridge(peer to peer).

Up to 20 groups of VPN Peer settings can be created.


Client Setting	
Mode	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
HostName	<input type="text"/>
Real IP/Domain	<input type="text"/>
VPN Port	<input type="text" value="656"/>
Description	<input type="text"/>

- **Mode:** Administrator can select Enable or Disable the service.
- **HostName:** Administrator can set VPN host name in this field.
- **Real IP/Domain:** Administrator can set remote real IP address or Domain name in this field.
- **VPN Port:** Administrator can set connection Port for VPN.
- **Description:** Enter the description for the VPN Peer. **(This is optional fill in and will not affect VPN connection settings)**

### Basic instructions for setting the program

In the two end points A and B for example

1. Set the VPN server on the A side, and download and store the VPN Public Key, the A Public Key upload it to the B endpoint for authentication. The same is true for the B endpoint setting. (Two-end exchange public key)



2. Establish remote VPN Server information and upload the remote Public Key to this location.



3. After completion, administrator can use ping command go to ping remote network IP address. If A ping to B side can get respond indicates that the VPN tunnel has been successfully established.


<pre>Connection-specific DNS Suffix . : Description . . . . . : Realtek Gaming USB 2.5GbE Family Controller Physical Address. . . . . : 00-E0-4C-68-00-B0 DHCP Enabled. . . . . : Yes Autoconfiguration Enabled . . . . : Yes Link-local IPv6 Address . . . . . : fe80::6dbb:e9be:1a09:9973%10(Preferred) IPv4 Address. . . . . : 192.168.101.63(Preferred) Subnet Mask . . . . . : 255.255.255.0</pre>	<pre>C:\Users\jacky&gt;ping 192.168.2.1 -t Pinging 192.168.2.1 with 32 bytes of data: Reply from 192.168.2.1: bytes=32 time=3ms TTL=64 Reply from 192.168.2.1: bytes=32 time=1ms TTL=64 Reply from 192.168.2.1: bytes=32 time=2ms TTL=64 Reply from 192.168.2.1: bytes=32 time=1ms TTL=64 Reply from 192.168.2.1: bytes=32 time=2ms TTL=64 Reply from 192.168.2.1: bytes=32 time=16ms TTL=64</pre>
A Side	B Side

4. Special attention to the fact that the respective Client settings of the final VPN server and the VPN Peer settings of both parties must be enabled for the VPN Peer connection to be successful.
5. Kindly remind, please set up correctly and enable the DHCP filtering function. When using DHCP Server to allocate IP, it can be enabled according to the environment to prevent the physical area networks at both ends from crossing the boundary and allocating IPs to each other, causing the IP obtained not to be the real IP allocation. You will then be unable to access the Internet normally. You must choose to enable filtering on either side to prevent non-local DHCP servers from assigning IPs and thus avoid cross-border assignments. Please pay special attention to this part and do not enable this feature on both ends. If DHCP filtering is enabled on both ends, a network logic error will occur, causing the VPN connection to fail.

### 3.8 PPTP Server Setup

	<p>This VPN function support three protocol are VPN Server 、PPTP/L2TP and IPsec, the VPN tunnel of these three types only select one VPN protocol to used it.</p>
---	---

Use the PPTP protocol to build a VPN tunnel; administrator can setup PPTP server of the VPN tunnel in the function.



Please click "System" → "PPTP Server Setup"



- **Connections:** Administrator can set connected VPN client Qty.
- **Local IP Address:** Set virtual IP address for VPN server.

This IP address is set as a VPN-specific virtual IP address tunnel, the IP address can't set same subnet of the WAN and LAN (network).

- **Remote Start/ End IP Address:** Set start to end IP address for dynamic configuration, can give VPN client automatically obtain a virtual IP address.
- **MPPT40/128:** Administrator can choose use VPN security for 40 or 128 bit.


## 3.9 L2TP Server Setup



This VPN function support three protocol are VPN Server、PPTP/L2TP and IPsec, the VPN tunnel of these three types only select one VPN protocol to used it.

Same as PPTP, L2TP protocol to build a VPN tunnel; administrator can setup L2TP server of the VPN tunnel in the function.

Please click “System” → “P2TP Server Setup”




➤ **Local IP Address:** Set virtual IP address for VPN server.



This IP address is set as a VPN-specific virtual IP address tunnel, the IP address can't set same subnet of the WAN and LAN (network).

➤ **Remote Start/ End IP Address:** Set start to end IP address for dynamic configuration, can give VPN client automatically obtain a virtual IP address.



➤ **Mode:** Administrator can choose Enable or disable this function.


➤ **Pre-shared Key:** Set a security key for Pre-shared Key

- **Client IP:** Set a IP address of client.
- **WAN ID:** Select a access passage.

## 3.10 PPTP/L2TP Account Setup


Create PPTP / L2TP authentication account with maximum of 60 VPN accounts.

Please click “System” → “PPTP/L2TP Account Setup”



Account List				Create Account
#	Username	PPTP Support	L2TP Support	Action
-	-	-	-	-


- **Create Account:** Administrator can click the button to create authentication account of client.



- **User Name/Password:** Set authentication account of name/password.
- **PPTP/L2TP Support:** Set account used to PPTP or L2TP protocol.

### Routing Rule:

Set routing of both network, As figure below, the local end is the Server endpoint and the remote end is the Client endpoint.



Example :

Local Subnet: 192.168.10.0/24


Remote Subnet : 192.168.20.0/24


Routing Rule	
Local Subnet	<input type="text" value="0.0.0.0/0"/>
Remote Subnet	<input type="text" value="0.0.0.0/0"/> <span>Add</span>

- **Local Subnet:** Set network subnet of local.
- **Remote Subnet:** Set network subnet of Remote.


### 3.11 PPTP/L2TP Client Setup

If remote have PPTP/L2TP VPN server, administrator can used PPTP/L2TP client function connection to remote VPN server.






Please click "System" → "PPTP/L2TP Client setup"



Client List <span style="float: right;">Create Client</span>				
#	Active	Mode	Server IP Address	Action
-	-	-	-	-


Please click the Create Client button to set client conditions. **U Up to 60 client of PPTP/L2TP Client can be created.**



A screenshot of the 'PPTP/L2TP Client Setup' configuration page. It features a section for 'Active' status with radio buttons for 'Enable' (selected) and 'Disable'. Below this is a section for 'PPTP/L2TP Client Settings' with radio buttons for 'Mode' (selected 'PPTP' and 'L2TP'). At the bottom, there are three input fields for 'Server IP Address', 'User Name', and 'Password'.

- **Mode:** Administrator can select use PPTP or L2TP protocol connection to remote VPN server. If VPN server used PPTP Protocol then please choose PPTP.
- **Server IP Address:** Administrator must set remote VPN server used real IP address.
- **User Name / Password:** Set VPN authentication account and password (Please Refer to 3.10 Account Setup)

If you use PPTP protocol, please select the encryption type, as shown below




**PPTP Setup**

MPPE40     Enable     Disable

MPPE128     Enable     Disable

- **MPPE40/128:** Enable or disable security options based on using remote VPN servers.

If you use L2TP protocol, please enter the Pre-share Key and confirm which WAN to use as the external VPN channel, as shown below



**L2TP Setup**

Over IPsec     Enable     Disable

Pre-shared Key   

WAN   




- **Over IPsec :** Choose to enable or disable the Over IPsec VPN protocol.
- **Pre-shared Key :** You can enter a set of password keys
- **WAN :** elect L2TP VPN through the WAN related user interface.

## 3.12 IPsec Setup




**This VPN function support three protocol are VPN Server 、 PPTP/L2TP and IPsec, the VPN tunnel of these three types only select one VPN protocol to used it.**

Administrator can create new VPN connection for the IPsec.  
Please Click “System” → “IPsec Setup”



➤ **Service:** You can choose to turn on or off this function service



- **Mode:** Administrator can be according to different needs select use LAN to LAN or Client to LAN.
- **WAN:** Administrator can choose use specific WAN Port connection.
- **Local ID Type:** Administrator can select use IP address or FQDN for Local IP Type.
- **Local Subnet:** Administrator must set Local Subnet for the VPN "LAN to LAN".
- **Local Nexthop:** Administrator can add a VPN Next hop address for Local.

- **Remote ID Type:** Administrator can select use IP address or FQDN for Remote IP Type.
- **Remote Subnet:** Administrator must set remote Subnet for the VPN "LAN to LAN".
- **Remote Nexthop:** Administrator can add a VPN Next hop address for Remote
- **Pre-shared Key:** Enter Pre-shared Key for VLAN.

<b>DPD</b>	<input checked="" type="radio"/> <b>Enable</b> <input type="radio"/> <b>Disable</b>
<b>DPD Delay</b>	<input type="text" value="30"/>
<b>DPD Timeout</b>	<input type="text" value="120"/>

- **DPD:** DPD (Dead peer detection) is a method that network devices use to verify the current existence and availability of other peer devices. The system can waiting for DPD acknowledgements (R-U-THERE-ACK messages) from the peer. **The DPD function must be enabled on both ends of the VPN host. The system on one side can wait for a delay time packet access from the remote stationary device and respond with the packet to ensure that the host knows that both parties are active. normal status. When no response message is received from the host after the set Timeout time, the host will use the DPD mechanism to automatically start the VPN reconnection process. This feature is enabled by default. Administrators are recommended to use this feature. This is to avoid the possibility of the VPN not being able to automatically reconnect after being disconnected.**
- **DPD Delay:** Administrator can set delay time (seconds) for DPD. **(The default value is 30 seconds for packet access to the opposite VPN host.)**
- **DPD Timeout:** Administrator can set timeout of times for DPD. **(The default value is 120 seconds. When the peer host does not respond normally according to the access period set by Delay, the DPD automatic VPN connection process is automatically started.)**

### IKE Policy:

This function is verification the VPN identity. The VPN to establish a connection with each other must be certified to establish a trust relationship between each other, this function supports IKE Phase 1/2.

☰ IKE Policy	
<b>IKE Mode</b>	<input type="radio"/> <b>Main</b> <input type="radio"/> <b>Aggressive</b>
<b>IKE Authentication</b>	<input type="text" value="MD5"/>
<b>Encryption</b>	<input type="text" value="3DES"/>
<b>DH Group</b>	<input type="text" value="DH1"/>

- **IKE Mode:** Administrator can select Main or Aggressive of the IKE. If device uses Router

mode then suggest use Main mode is high security.

- **IKE Authentication:** Administrator can select authentication method for MD5, SHA1, SHA2\_256.
- **Encryption:** Set encryption method for IKE. Administrator can select use 3DES and AES128/192/256.
- **DH Group:** Diffie-Hellma is key exchange. Allows two devices to establish a shared secret over an unsecure network. In terms of VPN it is used in the in IKE or Phase1 part of setting up the VPN tunnel. This DH Group support DH1/2/5/14.

### IPSec Policy:

**IPsec Policy**


<b>Security Protocol</b>	ESP
<b>ESP Authentication</b>	MD5
<b>ESP Encryption</b>	3DES
<b>Perfect Forward Secrecy</b>	<input type="radio"/> Enable <input type="radio"/> Disable
<b>DH Group</b>	DH1

- **Security Protocol:** The IPSec security use ESP protocol.
- **ESP Authentication:** Administrator can select authentication method for MD5, SHA1, SHA2\_256.
- **ESP Encryption:** Set encryption method for ESP. Administrator can select use 3DES and AES128/192/256.
- **Perfect Forward Secrecy:** Administrator can select enable or disable for DH Group.
- **DH Group:** Diffie-Hellman is a key exchange and supports DH1/2/5/14. This function mainly allows two parties to create keys through an unsecured channel without requiring any information from the other party.

## 3.13 Management

Administrators can specify geographical location of the system via instructions in this page and modify system login password and select use system login protocol by 80, 443, 23, 22 Port. The management page support syslog server function and system auto reboot function.

Please Click **“System”** ➔ **“Management”**



**System Language**

Language: English

---

**System Information**

System Name: DR-4000

Description: Multi WAN with Gigabit VPN Gateway

Location:

---

**Root Password**

New Root Password: |

Check Root Password:

---

**Ping Watchdog**

Ping Watchdog:  IP Address:

---

**Jumbo Frame**

Jumbo Frame: Enable

1Gbe port jumbo frames are 9K bytes

**Login Methods**

HTTP:  80 Port

HTTPS:  443 Port

Telnet:  23 Port

SSH:  22 Port

Host Key Footprint: ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAA **Generate Key**

Access WAN0:  Enable  Disable

Access WAN1:  Enable  Disable

Access WAN2:  Enable  Disable

---

**System Log Setup**

Remote Server:  Port: 514 Port

---

**Auto Reboot**

Type: Disable

---

**Wake On LAN**


Type: Disable

- **Language:** Administrators can choose to change the language of the English or Chinese.
- **System Information:** Administrator can set the system name / Description and Location.
- **Root Password:** Administrator can change system login password.
- **System Log Setup:** Administrator can be backup system log or authentication log to remote server. Please enter IP address and port of remote syslog server.

**System Log Setup**

**Remote Server**  127.0.0.1

**Port** 514 **Port**



- **Remote Server:** Set the IP address of the remote system Log server .
- **Port:** Set the port number of the remote system Log server. The default Port is 514.

➤ **Ping Watchdog :** Ping Watchdog helps administrator to automatically reboot the system when its not working properly.

**Ping Watchdog**

**Ping Watchdog**   IP Address


**Interval** 60 **Seconds**

**Delay** 100 **Seconds**


**Times of faults** 3 **times**

- **Ping Watchdog :** Set the IP address to be monitored for ping.
- **Interval :** Set the interval to ping the IP address.
- **Delay :** When ping fails, how long should you delay before ping again.
- **Times of faults :** When the above conditions are true multiple times, let the system reboot.

➤ **Jumbo Frame :** Can be enabled or disabled to determine whether all physical Ethernet ports use Gigabit 9K Jumbo Frame as the primary packet transmission format.




- **Login Methods:** Administrator can set system login protocol of the http/https/telnet and ssh.



- **HTTP Management** : Check this item will enable the WEB interface to enter the management interface. The default is port 80. (recommended port number between 1025 and 65535)
  - **HTTPS Management** : Check this item will enable the WEB interface to enter the management interface. The default is port 443. (recommended port number between 1025 and 65535)
  - **Telnet Management** : Check this item will enable Telnet to enter the management interface. The default is port 23. (recommended port number between 1025 and 65535)
  - **SSH Management** : Check this item will allow SSH to enter the management interface. The default port is 22.
  - **Host key Footprint** : Click to generate SSH certificate key.
- **Access WAN#:** If enable this WAN# then external (Internet) will can access management interface for DR-4000. The default is Disable. (This function can only be used in Router mode).
- **Auto Reboot:** The functions can Auto-reboot the system by Date/time management.


- **Daily** : Setting time to system reboot.



Auto Reboot

Type	Daily
Hour	08
Minute	08


- **Weekly** : Setting frequency (ex. Weekly) and time of system reboot



Auto Reboot

Type	Week
Weekly	Sunday
Hour	08
Minute	08

- **Monthly** : Setting Every month, fixed date and time to system reboot




Auto Reboot

Type	Month
Monthly	01
Hour	08
Minute	08

- **Wake On LAN:** This function can fix in the remote MAC address of network card to allow the system to wake up a remote network MAC address device immediately or periodically.

- **Daily** : Setting every day time for the system to wake up a device with a remote network MAC address.



Wake On LAN

Type	Daily
MAC Address	<input type="text"/> <span>Wake Now</span>
Hour	00
Minute	00

- **Weekly** : Setting frequency (ex. Weekly) time for the system to wake up a device with a remote network MAC address.

Wake On LAN

Type: Week

MAC Address:  Wake Now

Weekly: Sunday

Hour: 00

Minute: 00

- **Monthly** : Setting Every month time for the system to wake up a device with a remote network MAC address.

Wake On LAN

Type: Month

MAC Address:  Wake Now

Monthly: 01


Hour: 00

Minute: 00

## 3.14 Time Server

Administrator can select manual or via a NTP server to modify system time for the right local time. If select update the system time for manual, when administrator reboot system the system time will reply default.

If select update the system time for the NTP Server, system must set gateway and DNS server, the system can be connected internet.



System Time

Local Time: 2015/12/02 21:01:49


Mode:  NTP Server  Manual

---

User Setup


Date(Y/M/D): 2016 / 10 / 20

Time(H:M:S): 19 / 28 / 10 (GMT+8:00)




The screenshot shows the 'NTP Server' configuration window. It includes a 'Default NTP Server' dropdown menu with 'time.stdtime.gov.tw' selected. Below it is a text input field for 'NTP Server' also containing 'time.stdtime.gov.tw'. The 'Time Zone' is set to '(GMT+08:00) Beijing, Hong Kong, Singapore, Taipei'. At the bottom, there are radio buttons for 'Daylight Saving Time', with 'Disable' selected.

- **Mode:** Administrator can select NTP Server or Manual.
- **NTP Server:** System can auto update the system time. Administrator needs setting as NTP Server. **For example, select the time server of "cerio.com.tw" on the Internet as the basis for NTP time calibration as follows.**



This screenshot shows the 'NTP Server' configuration window with the 'Default NTP Server' dropdown menu open. The list of options includes 'cerio.com.tw', 'Customize Time Server', 'time.google.com', 'time.windows.com', 'time.nist.gov', 'time-nw.nist.gov', 'murgon.cs.mu.OZ.AU', 'ns2.pads.ufrj.br', 'nist1.symmetricom.com', 'time.stdtime.gov.tw', and 'pool.ntp.org'. 'cerio.com.tw' is highlighted in the list.

- ✓ **Default NTP Server:** Administrator can select NTP Server.
- ✓ **NTP Server:** Administrator can setting as NTP Server.
- ✓ **Time Zone:** Administrator can select a desired time zone from the drop-down list.
- ✓ **Daylight saving Time:** Enable or disable Daylight saving.
- **Manual:** Administrator need to set the system time.



The screenshot shows the 'User Setup' configuration window. It features two rows of date and time input fields. The first row is for 'Date(Y/M/D)' with values 2015, 9, and 9. The second row is for 'Time(H:M:S)' with values 17, 49, and 15. A '(GMT+8:00)' label is positioned to the right of the time fields.




Notice

This product supports hardware battery power supply to RTC (Real Time Clock Module) IC real-time clock memory storage module design. When "Manual Update" is selected, if the time cannot be saved and it will always be invalid and return to the default time, then The machine board hardware battery must be checked and replaced.


## 3.15 SNMP

SNMP is an application-layer protocol that provides a message format for communication between SNMP managers and agents. By enabling SNMP function, the administrator can obtain the system information remotely.

Please click on **System** -> **SNMP** and follow the below setting.




### SNMP v2c function



- **Active:** Administrator can select Enable or Disable the service.
- **RO Community:** Set a community string to authorize read-only access.
- **RW Community:** Set a community string to authorize read/write access.

### SNMP v3 function



- **Active:** Administrator can select Enable or Disable the service.
- **RO username:** Set a community string to authorize read-only access.
- **Ro password:** Set a password to authorize read-only access.
- **RW username:** Set a community string to authorize read/write access.
- **RW password:** Set a password to authorize read/write access.

## SNMP Trap

Events such as cold start interface up & down, and association & disassociation will report to an assigned server.




The image shows a web-based configuration interface for SNMP Trap. At the top, there is a title bar with a home icon and the text "SNMP Trap". Below the title bar, there are two radio buttons: "Enable" and "Disable". The "Disable" radio button is selected. Below the radio buttons, there are five input fields labeled "Community", "IP 1", "IP 2", "IP 3", and "IP 4".

- **Active:** Administrator can select Enable or Disable the service.
- **Community:** Set a community string required by the remote host computer that will receive trap messages or notices send by the system.
- **IP(1~4) :** Enter the IP addresses of the remote hosts to receive trap messages.

## 3.16 DDNS

Dynamic Domain Name Server, referred to as DDNS dynamic DNS technology. According to the Internet domain name establishment rules, domain names must follow a fixed IP address. However, the dynamic DNS system provides a fixed name server (Name server) for the dynamic domain, which allows external users to connect to the dynamic user's URL through real-time updates. **This system has built-in support for 2 service providers, namely dyndns and no-ip.**

Please click on **System** -> **DDNS** and follow the below setting.



Select and edit settings according to the corresponding WAN. **Supports 3 sets of corresponding WAN IP settings..**

#	Active	Provider	WAN	Hostname	Edit
0	InActive	dyndns	Auto		Edit
1	InActive	dyndns	Auto		Edit
2	InActive	dyndns	Auto		Edit

DDNS Setup

Active  Enable  Disable

Provider:

WAN:

Hostname:

Username:

Password:

Interval:  Minute


- **Active:** Choose to enable or disable the function.
- **Provider:** Choose the Service provider , **built-in support for 2 service providers, namely dyndns and no-ip.**
- **WAN:** Select the port for external connection of this machine
- **Hostname:** Enter the host name
- **Username/Password:** Enter the account password applied by the DDNS service provider
- **Interval:** Enter the interval for the host to automatically provide the physical address to the DDNS service provider.

## 3.17 Log Server Setup

If devices used CERIO products and support syslog server function, the devices log can be

transferred to this server and record devices log. Administrator can set storage space for the session/authentication and devices system log.

System can use e-mail send log Message to administrator.



☰ Radius Log Setup

**Radius Log Size**  MB

☰ Session Log Setup

**Session Log Size**  MB

**Reorder Mode**  ▼

☰ Authentication Log Setup

**Authentication Log Size**  MB

**Reorder Mode**  ▼

☰ System Log Setup

**System Log Size**  MB

**Reorder Mode**  ▼

- **Log Size:** Administrator can set storage space for RADIUS/session/authentication and system log.( max.512MB)
- **Recorder Mode:** The function can auto clear Log information or stop services.
  - **Cycle:** System will auto clear log by cycle.
  - **Retention Period:** System will auto clear log by Retention Period. Administrator can set

days for retention period. (Max. 90 days)



Notice

When the log record file exceeds the set space size, the system will stop recording, so be sure to calculate the retention days and space size. For example, if the retention period is set to 7 days, but the storage space is full on the third day, the system will automatically stop recording at this time.

- **Stop Service:** If the system storage is full, the system will auto stop recording.

## E-Mail Message setting

Administrator can set E-Mail messenger format and set **3.16 Notification Setup** function send e-mail to administrator.

**E-Mail Message Format**

**Subject**

%t, %h, %l, %e, %s, %p


**Subject: Radius Log happend Full In 2016-11-21 16:26**  
**Message: 2016-11-21 16:26, DR-3000, Radius Log, Full, 236MB, 95%**

Message Format	
Format	Description
%h	Hostname
%t	Time
%l	Log Type(Radius Log/Session Log/Authentication Log/System Log)
%s	File Size
%p	File Percentage
%e	Event Type(Full/ Stop Service/ Start Service)


## 3.18 Notification Setup

Administrator can automatically send the notification of Radius Log, Session Log, Authentication Log and System Log of 2 particular E-mail addresses. The E-Mail notification setting support SMTP server test, once administrator completed setting up of SMTP, server will able to use the test tool to confirm SMTP is working properly.

Please click “System” → “Notification,” functions of Notification E-mail Setup will appear, and fill in the related information, and select the desired function, and then, click on “Save” to apply the settings.



- **SMTP1/2 Service:** Administrator can select Enable or Disable the SMTP functions. If administrator select enable the function will following explains how to configure the SMTP functions.



- **Sender From:** Administrator can set E-Mail address by from.

- **SMTP Server:** Administrator can set E-Mail SMTP server.
- **Port:** Administrator can set SMPT Server used Port.
- **Encryption:** Administrator can select use TLS or SSL encryption type for the SMPT Server.

Encryption  ▼

- None
- TLS
- SSL

- **Authentication:** If SMTP Server must use authentication, Administrator can select enable the SMTP server authentication for E-Mail user account.

### Notification Setup

Administrator can set frequency or time for the RADIUS, Session, Authentication and System Log Capacity, and send to administrator E-Mail. For example:

**Detect Event Frequency Setup**

<b>Radius Log Capacity</b>	<input type="text" value="2"/>	<input type="button" value="Minutes"/>
<b>Session Log Capacity</b>	<input type="text" value="2"/>	<input type="button" value="Minutes"/>
<b>Authentication Log Capacity</b>	<input type="text" value="2"/>	<input type="button" value="Minutes"/>
<b>System Log Capacity</b>	<input type="text" value="20"/>	<input type="button" value="Minutes"/>

### Receiver E-Mail List

Administrator can click “Create Receiver E-Mail” button to add administrator E-mail address(es.)


**Receiver E-Mail List** Create Receiver E-Mail

#	Receiver E-Mail	Radius	Authentication	Session	Syslog	Action
1	████████@cerio.com...	Off	Off	Off	On	<input type="button" value="Edit"/> ▼
2	████████.net.net	Off	On	Off	On	<input type="button" value="Edit"/> ▼
3	████████@gmail.com	Off	Off	Off	On	<input type="button" value="Edit"/> ▼
4	████████.net.net	Off	Off	Off	On	<input type="button" value="Edit"/> ▼
5	████████@gmail.com	Off	Off	Off	On	<input type="button" value="Edit"/> ▼

- **Receiver E-Mail:** Administrator can set receiver e-mail addresses.
- **Edit:** Administrator can select the **Radius, Authentication, Session, and System Log**, to receiver Emails through **Edit** function.

## Deleting the Notification

Administrator can delete the notifications setting of receiver E-mail set previously.




Create Receiver E-Mail	
Syslog	Action
On	Edit
On	Delete

## 4. Account

This function is a RADIUS server such as the Cerio APs to utilize the RADIUS server authentication of **DR-4000**, and its many authentication types. When Cerio APs enable authentication through external RADIUS server, administrators must first set the IP address of **DR-4000** in each managed access point to properly redirect authentication clients.

Cerio's **DR-4000** Account functions support Package, Pregenerated Tickets and remote LDAP(AD) authentication type.

### 4.1 RADIUS Server



- **Service:** Administrator can select Enable or Disable the RADIUS Server.
- **Authentication Port:** Administrator can set authentication port for RADIUS Server, the default port is 1812.
- **Accounting Port:** Administrator can set accounting port for RADIUS Server, the default port is 1813.
- **Radius Secret:** Administrator can set password (Secret key) for RADIUS Server.

### 4.2 Remote LDAP Setup

Remote LDAP Setup enables Remote LDAP authentication for managed access points.

Administrators wishing to enable Remote LDAP authentication must copy and paste **DR-4000's** LDAP Server "**RADIUS Port**" number into the managed APs "Authentication Port" box, which is found in the managed Cerio APs "**Radius Setup**" window.

Administrator can set up 4 remote LDAP Server.

**LDAP Server**

Service  Enable  Disable

Radius Port

Radius Secret

- **Service:** Administrator can select Enable or Disable the authentication function.
- **Radius Port:** Administrators can set the Radius server port of the **DR-4000** to provide such as Cerio APs links. If Cerio APs set this Radius Port will can use remote LDAP(AD) type to authentication.
- **Radius Secret:** Administrator can set password (Secret key) for RADIUS Server.

LDAP Server List				
#	Service	IP Address	Base DN	Action
1	<span style="background-color: #f08080; padding: 2px;">Off</span>			<span style="background-color: #2e8b57; color: white; padding: 2px;">Edit</span>
2	<span style="background-color: #f08080; padding: 2px;">Off</span>			<span style="background-color: #2e8b57; color: white; padding: 2px;">Edit</span>
3	<span style="background-color: #f08080; padding: 2px;">Off</span>			<span style="background-color: #2e8b57; color: white; padding: 2px;">Edit</span>
4	<span style="background-color: #f08080; padding: 2px;">Off</span>			<span style="background-color: #2e8b57; color: white; padding: 2px;">Edit</span>

- **Edit:** Administrator can click Edit to set remote LDAP Server information.

**LDAP Server Setup**

Service  Enable  Disable

IP Address

Port

Username

Password

Base DN

Account Attribute

Identity

- **Service:** Administrator can select Enable or Disable the function.
- **IP Address:** Set IP address for remote LDAP(AD) server.
- **Port:** Set Port for remote LDAP(AD) server.
- **Username:** Set login account for remote LDAP(AD) server.
- **Password:** Set login account use password for remote LDAP(AD) server.

- **Base DN:** Set Base DN path for remote LDAP(AD) server.
- **Account Attribute:** Set LDAP cn account for remote LDAP(AD) server.

## LDAP Setting

Administrator can set remote LDAP(AD) timeout.

**LDAP Settings**

<b>Timeout</b>	<input type="text" value="4"/>	<b>Seconds</b>
<b>Time Limit</b>	<input type="text" value="3"/>	<b>Seconds</b>
<b>Net Timeout</b>	<input type="text" value="1"/>	<b>Seconds</b>

## 4.3 Package Setup

Administrator can set internet time rules for package authentication type.

Package List							Create New Package
#	Name	Description	Session Time	Traffic Volume	Expire After	Expiration	Action
0	TEST-1	no time		0B			<span style="background-color: #28a745; color: white; padding: 2px 5px;">Edit</span> ▼
1	test-2	60Mbps Trafflo		60.00MB			<span style="background-color: #28a745; color: white; padding: 2px 5px;">Edit</span> ▼
2	test-3	use 120 minutes time	2Hour(s)	0B			<span style="background-color: #28a745; color: white; padding: 2px 5px;">Edit</span> ▼
3	Test-4	use 120 minutes expl...		0B	2Hour(s)		<span style="background-color: #28a745; color: white; padding: 2px 5px;">Edit</span> ▼

- **Create New Package:** Administrator can click “**Create New Package**” button to set package rules.
- **# :** Package list (0~9) is Network control server (SP-800) code, administrator can choose code to print account.


**Package Setup**

<b>Package Name</b>	<input type="text" value="(4-32 chars)"/>
<b>Description</b>	<input type="text" value="(4-64 chars)"/>
<b>Traffio Volume</b>	<input type="text"/> <b>MB</b>
<b>Session Time</b>	<input type="text"/> <b>Minutes</b>
<b>Expire After</b>	<input type="text"/> <b>Minutes</b>
<b>Expiration</b>	<input type="text" value="Unlimited"/> ▼

- **Package Name:** Administrator can set Identify name for the package rules.
- **Description:** Administrator can set the description for package rules.
- **Traffic Volume:** Administrator can set authentication account use traffic limit for the package rules.
- **Session Time:** Administrator can set authentication account use session limit for the package rules. (After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in. )
- **Expire After:** Administrator can set authentication account use how many hours expire.( After the account is signed in, the system start counted time until the end time.)
- **Expiration:** Administrator can select Unlimited or Per Day or Until Time.



- ✓ **Unlimited:** After the account is signed in, the system does not count the time
- ✓ **Per Day:** After the account is signed in, the system start counted time until the end time.
- ✓ **Until Time:** After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in.



- **User Name Length:** Administrator can set account length limit for package rules.
- **User Name Type:** Administrator can create account use digit or Letters or Mix for



package rules. If administrator select Letters or Mix can filter L/l/digit 1 and O/ digit 0 and U/V for letters and Mix.

- **Password Length:** Administrator can set password length limit for account.
- **Password Type:** Administrator can set password use digit or Letters or Mix for account. If administrator select Letters or Mix can filter L/l/digit 1 and O/ digit 0 and U/V for letters and Mix.

## 4.4 Create An Account

Administrator can set and create an account of validity for the RADIUS Server.

Please click **“Account”** → **“Create an account”**



The 'Account Setup' form contains the following fields and options:

- User Name:** Text input field with a placeholder '(4-32 chars)'. The field is highlighted with a red box.
- Password:** Text input field with a placeholder '(4-32 chars)'. The field is highlighted with a red box.
- Paokage:** Dropdown menu with 'Test-4 (use 120 minutes expire)' selected. A green 'Apply' button is to the right.
- Trafflo Volume:** Text input field with '0' and a unit selector 'MB'.
- Session Time:** Text input field with '0' and a unit selector 'Minutes'.
- Expire After:** Text input field with '0' and a unit selector 'Minutes'.
- Expiration:** Radio buttons for 'Disable' (selected) and 'Enable'.

- **User Name :** Administrator can set an account for RADIUS Server.

- **Password** : Enter Password for user name account.
- **Package**: Administrator can choose apply mechanically Package function policy.
- **Traffic Volume**: Administrator can set authentication account use traffic limit for the package rules.
- **Session Time**: Administrator can set authentication account use session limit for the package rules. (After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in. )
- **Expire After**: Administrator can set authentication account use how many hours expire.( After the account is signed in, the system start counted time until the end time.)
- **Expiration**: Administrator can select Unlimited or Per Day or Until Time.





- **Unlimited**: After the account is signed in, the system does not count the time
- **Per Day**: After the account is signed in, the system start counted time until the end time.
- **Until Time**: After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in.

## 4.5 Search Account

Administrator can search all account in the databases. The search function built-in smart-search engine, administrator can set want to query account the conditions.

Please click **“Account”** → **“Search Account”**

**Expiration Time**

Expiration: < less than

Date(Y/M/D): 2016 11 24

Time(H:M:S): 10 24 47


Administrators can choose different data type in the search engines.

- **None:** The program doesn't judge characters, search all the information
- **Greater then:** Search values for greater than
- **Equal:** Search values for equal.
- **Less then:** Search values for less then.
- **Between:** Search values for between.
- **Like:** Search similar strings.

## 4.6 Regenerated Tickets DB

Administrators can use system auto create accounts in a databases.

Please click “Account” → “Regenerated Tickets DB” to create databases.



**Import DB**

Type: SQL

File:  Import

未選擇檔案。

**DB List** Create New Project

#	Project	Session Time	Traffic Volume	Expire After	Expiration	Count	Action
-	-	-	-	-	-	-	-

Administrator can click Create New Project to set function.

**Project Setup**

**Project Name**

**Traffic Cycle**

**Traffic Volume**  MB

**Session Time Cycle**

**Session Time**  Minutes

**Expire After**  Minutes

**Expiration**  Disable  Enable

- **Project Nama:** Administrator can set a Databases name.

**Traffic Cycle**

**Traffic Volume**

**Session Time Cycle**

- Total
- Daily
- Weekly
- Monthly

- **Traffic Cycle:** There is a reset period for traffic usage, and the pre-vouched account password will be eligible for repeated active use due to this reset period.
  - ✓ **Total** : Based on a one-time total calculation, the total amount of pre-ticketed account traffic will no longer be usable after it is exhausted.
  - ✓ **Daily** : Set "Daily" as the limit traffic reset to zero cycle period. The system fixes 00:00 every day as the "Day" reset point.
  - ✓ **Weekly** : Set "weekly" as the cycle period for the quota traffic to be reset to zero. The system fixes 00:00 every Sunday as the "week" reset point.
  - ✓ **Monthly** : Set "monthly" as the cycle period for resetting the limit traffic to zero. The system fixes 00:00 on the last day of each month as the "month" reset point.
- **Traffic Volume:** Administrator can set authentication account use traffic limit for the package rules.

<b>Session Time Cycle</b>	Total
<b>Session Time</b>	Total
<b>Expire After</b>	Daily
	Weekly
	Monthly

- **Session Time Cycle:** The session time uses a reset period, and the pre-ticket account password will be eligible for repeated and active use due to this reset period.
  - ✓ **Total :** Calculated based on a one-time total, the pre-voucher account password Session time expires and can no longer be used.
  - ✓ **Daily :** Set "Daily" as the Session available time reset to zero cycle period, and the system fixes 00:00 every day as the "Day" reset span point.
  - ✓ **Weekly :** Set "weekly" as the reset zero cycle period for the session's available time. The system fixes 00:00 every Sunday as the "week" reset span point.
  - ✓ **Monthly :** Set "monthly" as the reset zero cycle period for the session's available time. The system fixes 00:00 on the last day of each month as the "month" reset point.
- **Session Time:** Administrator can set authentication account use session limit for the package rules. (After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in. )
- **Expire After:** Administrator can set authentication account use how many hours expire.( After the account is signed in, the system start counted time until the end time.)
- **Expiration:** Administrator can select Unlimited or Per Day or Until Time.

<b>Expiration</b>	Unlimited
	Unlimited
	Per Day
	Until Time

- **Unlimited:** After the account is signed in, the system does not count the time
- **Per Day:** After the account is signed in, the system start counted time until the end time.
- **Until Time:** After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in.

**Pre-generated Rule**

**User Name Length**

**User Name Type**  Digit  Letters  Mix

No L/I/1  No O/0  No U/V

**Password Length**

**Password Type**  Digit  Letters  Mix

No L/I/1  No O/0  No U/V

**Ticket Number**


- **User Name Length:** Administrator can set account length limit for package rules.
- **User Name Type:** Administrator can create account use digit or Letters or Mix for package rules. If administrator select Letters or Mix can filter L/I/digit 1 and O/ digit 0 and U/V for letters and Mix.
- **Password Length:** Administrator can set password length limit for account.
- **Password Type:** Administrator can set password use digit or Letters or Mix for account. If administrator select Letters or Mix can filter L/I/digit 1 and O/ digit 0 and U/V for letters and Mix.
- **Ticket Number:** Administrator can set number in the databases, the system will auto create accounts

## 4.7 Thermal Printer Setup


The function must match Account Ticket Generator POS System for Cerio's SP-800-PRINTER / SP-800-QRCPT.

Application architecture is as follows.

**# Match SP-800-PRINTER**



## # Match SP-800-QRCPT



Printer Setup	
IP Address	192.168.2.253
Command Port	5000
Printer Type	Normal Thermal Printer
GOM Port	COM1
New Look Password	1234
Description	

- **IP Address:** Please set IP address for Network control server (SP-800)
- **Command Port:** Enter command port for Network control server (SP-800)
- **Printer Type:** Administrator can select Normal Thermal Printer or QR Code Thermal Printer.

- **Normal Thermal Printer:** If use Cerio’s SP-800-PRINTER POS system, administrator can select Normal Thermal Printer function.
- **QR Code Thermal Printer:** If use Cerio’s SP-800-QRCPRT POS system, administrator can select QR Code Thermal Printer function.
- **COM Port:** Administrator can select connected COM1/2 or RJ-45 for Printer Port.
  - **RJ-45:** If printer type selected QR Code Thermal Printer, administrator can select use RJ-45 and set Printer IP address.

<b>COM Port</b>	RJ-45
<b>Printer IP Address</b>	192.168.2.252
<b>Printer Port</b>	9100
<b>QRCode Type</b>	Small

- ✓ **Printer IP Address:** Administrator can set IP address for QR code Printer.
- ✓ **Printer Port:** Administrator can set Port for QR code Printer. The default Port is 9100 for Cerio’s SP-800-QRCPRT
- ✓ **QR Code Type:** Administrator can select print QR Code size or close.
- **New Look Password:** The password is Network control server(SP-800) connect to **DR-4000** use key lock. Administrator can change password, default password is 1234
- **Description:** Administrator can enter Description.

## # Package List

Print tickets account must have created Package; administrator can refer to “[4.3 Package Setup](#)” description.

Package List			
Package#	Enable	Name	Description
1	<input type="checkbox"/>	TEST-1	no time
2	<input type="checkbox"/>	test-2	60Mbps Trafflo
3	<input type="checkbox"/>	test-3	use 120 minutes time
4	<input type="checkbox"/>	Test-4	use 120 minutes expl...

Administrator can choose box to enable Packages rule.

## 4.8 History Log

The Page can display account login/logout information.

#	Username	Login Time	Logout Time	IP	MAC	Input Bytes	Output Bytes	AP IP	AP MAC	Status
-	-	-	-	-	-	-	-	-	-	-

## 4.9 Online Log

The Page can display online user information. The online user information must match Cerio's AP's; Administrator must enable RADIUS Accounting Port 1813 in the Cerio's AP's, as follows

### # Cerio's APs for CenOS5.0 interface

**Radius Setup**

Radius  Enable  Disable

Display Name:

Primary Server IP:

Secondary Server IP:

Authentication Port:  Port

**Accounting Service**    Port

Authentication Type  PAP  CHAP

Secret Key:

### # DR-4000 online Log page

#	Username	Login Time	Session Time	IP	MAC	Input Bytes	Output Bytes	AP IP	AP MAC
-	-	-	-	-	-	-	-	-	-

## 4.10 Database Maintenance

Administrator can clear account for Expiration / Pregenerated / All databases.

Account Database	
Expiration of Account	<input type="text" value="0"/> <input type="button" value="Clear"/>
Pregenerated of Account	<input type="text" value="0"/> <input type="button" value="Clear"/>
All of Account	<input type="text" value="0"/> <input type="button" value="Clear"/>



Administrator click "Clear" button, the databases all account will be deleted.


## 5. Advance

### 5.1 IP Filter

Can allow or deny filter ingress or egress packets from specific source and/or to destination IP address on wired (LAN) or (WAN) ports. Filter rules support IP/ Port Groups, could be used to filter unicast or multicast packets on different protocols as shown in the IP Filter Setup. Important to note that IP filter rules has precedence over Access control rules.

Administrator can set IP Filter rules: 64

Please click "Advance" → "IP Filter" setup.



#	Active	Comment	Protocol	Action	Source Address/Mask	Source Port	Destination Address/Mask	Destination Port	Edit
1	InActive	-	ALL	Deny	-	-	-	-	Edit
2	InActive	-	ALL	Deny	-	-	-	-	Edit
3	InActive	-	ALL	Deny	-	-	-	-	Edit
4	InActive	-	ALL	Deny	-	-	-	-	Edit
5	InActive	-	ALL	Deny	-	-	-	-	Edit
6	InActive	-	ALL	Deny	-	-	-	-	Edit
7	InActive	-	ALL	Deny	-	-	-	-	Edit
8	InActive	-	ALL	Deny	-	-	-	-	Edit
9	InActive	-	ALL	Deny	-	-	-	-	Edit
10	InActive	-	ALL	Deny	-	-	-	-	Edit
11	InActive	-	ALL	Deny	-	-	-	-	Edit
12	InActive	-	ALL	Deny	-	-	-	-	Edit
13	InActive	-	ALL	Deny	-	-	-	-	Edit

➤ Please click **Edit** button to setting IP filter.

- **Active:** Administrator can selected Enable or Disable for the IP filter rules function.
- **Comment:** Enter rule description.

## IP Filter Rules

- **Policy:** Administrator can select Deny or Pass for IP filter rules.
- **Protocol:** Administrator can select type for IP protocol.
- **Schedule:** Can choose to use rule by “Time Policy”.

## Source Rule

☰ Source Rule

**Self**    Enable    Disable

**Source Address/Mask**

**Source IP Group**  ▼

**Interface**  ▼

- **Self:** Administrator can choose Enable or Disable, if administrator select Enable, the source is self.
- **Source Address/Mask:** Administrator can set IP address and Mask for source.
- **Source IP Group:** Administrator can select belonging to group for IP Address.
- **Interface:** Administrator can select interface for source.

☰ Destination Rule

**Self**    Enable    Disable

**Destination Address/Mask**

**Destination IP Group**  ▼

**Interface**  ▼

- **Self:** Administrator can choose Enable or Disable, if administrator select Enable, the source is self.
- **Destination Address/Mask:** Administrator can set IP address and Mask for destination.
- **Destination IP Group:** Administrator can select belonging to group for IP Address.
- **Interface:** Administrator can select interface for destination.

## 5.2 IP Group

Administrator can create IP group for IP address range or subnet.

#	Comment	Edit
1	IP Group 0	<a href="#">Edit</a>
2	IP Group 1	<a href="#">Edit</a>
3	IP Group 2	<a href="#">Edit</a>
4	IP Group 3	<a href="#">Edit</a>
5	IP Group 4	<a href="#">Edit</a>

Please click “**Edit**” button to create new IP Groups.


➤ **Comment:** Enter IP Group description.

➤ **IP Address Type:** Administrator can select single / range / subnet type to set IP Address.

- **Single IP Address:** Enter single IP Address.
- **Range:** Enter start / end IP address.
- **Subnet:** Enter Net/Mask.


## 5.3 Port Group

Administrator can create Port group



#	Comment	Edit
1	Port Group 0	<a href="#">Edit</a>
2	Port Group 1	<a href="#">Edit</a>
3	Port Group 2	<a href="#">Edit</a>
4	Port Group 3	<a href="#">Edit</a>
5	Port Group 4	<a href="#">Edit</a>
6	Port Group 5	<a href="#">Edit</a>

Please click “**Edit**” button to create new Port Groups.



- **Comment:** Enter Port Group description.
- **Port Type:** Administrator can select single or range Port.
- **Port:** Administrator can set service port.

## 5.4 MAC Filter

Allows creating MAC filter rules to allow or deny unicast or multicast packets from limited number of MAC addresses. Important and must note. That MAC filter rules have precedence over IP Filter rules.

#	Active	Comment	MAC Address	Policy
1	<input type="checkbox"/>			Always Run
2	<input type="checkbox"/>			Always Run
3	<input type="checkbox"/>			Always Run
4	<input type="checkbox"/>			Always Run
5	<input type="checkbox"/>			Always Run

- **Mode:** Administrator can select Deny or Allow.
  - **Deny:** The MAC Filter List will be **denied** to access (LAN to WAN). Others will be allowed.
  - **Allow:** The MAC Filter List will be **allowed** to access (LAN to WAN). Others will be denied.
- **Comment:** Enter the description of MAC filter rule.
- **MAC Address:** Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click “**Add**” button, then the MAC address should display in the MAC Filter List.
- **Policy:** Administrator can select to use rule by “**Time Policy**”.

## 5.5 Virtual Server

The “**Virtual Server**” can also referred to as “Port Forward” as well and used interchangeably. Resources in the network can be exposed to the Internet users in a controlled manner including on-line gaming, video conferencing or others via Virtual Server setup. Don’t repeat ports’ usage to avoid confusion.

Suppose you want to assign ports 21-25 to one FTP, Telnet and SMTP server (A in the example), and port 80 to another (B in the example). You assign the LAN IP addresses and the ISP assigns

the WAN IP address. The NAT network appears as a single host on the Internet.

**Virtual Server Rules**

**Active**    Enable    Disable

**Comment**  

**Protocol**    TCP    UDP

**Interface**  

**Public Port**  

**Private IP Address**  

**Private Port**  


**Schedule**

- **Active:** Administrator can select Virtual server rule to Enable or disable.
- **Comment:** Enter the description of virtual server rule.
- **Protocol:** Administrator can select service protocol of TCP or UDP.
- **Public Port:** Enter service port No. for public.
- **Private IP Address:** Enter corresponding IP address for internal.
- **Private Port:** Enter internal service port No. for private.
- **Schedule :** Administrator can select to used rule of “**Time Policy**”

## 5.6 Access Control


The Access Control function administrator can to block or allow specific kinds of TCP/UDP/ICMP protocol, such as Internet access, designated services, and websites. The Access Control function can set 20 profiles.

Please click on **Advance -> Access Control** and follow the below setting.




#	Active	Comment	Protocol	Edit
1	InActive	-	ANY	Edit
2	InActive	-	ANY	Edit
3	InActive	-	ANY	Edit
4	InActive	-	ANY	Edit
5	InActive	-	ANY	Edit

- **#** : Display access control list.
- **Active** : Display Active or InActive for the access control rule.
- **Comment**: Display information for the rule.
- **Protocol** : Display information for the protocol.
- **Edit** : Administrator can click the button to set Access Control rule.



### # Access control rules :


- **Active** : Administrator can select Enable or Disable for the Access control rule.
- **Comment** : Administrator can enter comment for the role.
- **Protocol** : Administrator can to select management protocol by TCP/UDP/ICMP/Content Filter/Application and Domain Filter.



- ✓ **ANY:** Select "Any" is all deny Protocol, administrator can filter local IP / IP range go to destination IP / IP range and use protocol.
- ✓ **TCP:** Deny TCP Protocol, Administrator can set TCP protocol and assign IP / IP range.
- ✓ **UDP:** Deny UDP Protocol, Administrator can set UDP protocol and assign IP / IP range.
- ✓ **ICMP:** Deny ICMP Protocol, Administrator can assign IP / IP range.
- ✓ **Content Filter:** Administrator can set web Keyword to filter.
- ✓ **Application:** System built-in multiple applications data, Administrator can select application data to filter.
- ✓ **Domain:** Administrator can set domain name to filter.
  - **Schedule :** The rule can apply Time Policy.

## 5.7 IP Routing Setup

The IP Routing Settings allows configure routing feature in the gateway. The system supports RIP(Routing Information Protocol ) and OSPF(Open Shortest Path First) dynamic routing and allows you to manually configure static network routes. Please click on Advance -> IP Routing and follow the below setting.




➤ **OSPF Settings :**

OSPF (Open Shortest Path First) is a router protocol used to find the best path for packets as they pass through a set of connected networks.

- **Service:** Administrator can select enable or disable Service for OSPF.
- **Route ID:** Administrator can select WAN0~3 and VLAN0~7 interface (IP) for the Route ID.
- **Distribute RIP over OSPF:** Administrator can select enable or disable, if select enable system can allow RIP routes will redistributed into OSPF.

*OSPF Network Setting*



The screenshot shows the 'OSPF Network Settings' window. It contains several rows, each with a label on the left and a text input field on the right. The labels are: 'WAN0 Area', a dot, 'WAN3 Area', 'VLAN0 Area', a dot, a dot, and 'VLAN7 Area'. Each text input field contains the number '0'. There are also small square checkboxes to the left of each input field.

- ✓ **#Area:** Represents the area code of the OSPF routing protocol, which can be any digit in decimal, default is 0.

➤ **RIP Settings :**

RIP defines a way for routers, which connect networks using the IP, to share information about how to route traffic among networks. RIP prevents routing loops by implementing limit on the number of hops allowed in a path from source to destination. The maximum number of hops allowed for RIP is 15, which limits the size of networks that RIP can support. A hop count of 16 is considered an infinite distance and the route is considered unreachable.



The screenshot shows the 'RIP Settings' window. It has two rows of radio button options. The first row is labeled 'Service' and has 'Enable' (unselected) and 'Disable' (selected) options. The second row is labeled 'Distribute OSPF over RIP' and has 'Enable' (unselected) and 'Disable' (selected) options.

- **Service:** Administrator can select enable or disable Service for RIP.
- **Distribute OSPF over RIP:** Administrator can select enable or disable, if select enable system can allow OSPF routes will redistributed into RIP.

☰ RIP Side(Devices) Settings

WAN0	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
.	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
WAN3	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
WAN3	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
VLAN0	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
.	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
VLAN7	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable

- ✓ **RIP Side(Devices) Settings:** Administrator can choose enable or deniable for WAN/LAN interface

## 5.8 IP Routing Rule Setup

Advance ▾

IP Filter

IP Group

Port Group

---

MAC Filter

Virtual Server

Access Control

---

IP Routing Setup

IP Routing Rule Setup

---

Time Polloy

☰ IP Routing Rule List

#	Active	Destination Net/Mask	Via	OSPF	RIP	Edit
1	InActive	-	-	off	off	Edit
2	InActive	-	-	off	off	Edit
.						
.						
19	InActive	-	-	off	off	Edit
20	InActive	-	-	off	off	Edit


Please click **Edit** button to setting IP Routing Rule.

☰ IP Routing Rule Settings

Service	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
Destination Net/Mask	<input type="text"/>	
Via	<input checked="" type="radio"/> Gateway	<input type="radio"/> Interface
Gateway	<input type="text"/>	
OSPF	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
RIP	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable

- **Service:** Administrator can select Enable or Disable for the IP Routing Rule.
- **Destination Net/Mask:** If administrator select enable for service, will be able set destination Net/Mask.
- **Via:** Administrator can select use Gateway or Interface
  - **Gateway:** enter Gateway IP address.
  - **Interface:** Select WAN / LAN interface.
- **OSPF/RIP:** Administrator can select enable or disable, if select enable will apply “IP Routing Setup” of OSPF/RIP function.

## 5.9 Time Policy



Policy List			
#	Comment	Mode	Edit
1	Polloy 1	On Sochedule	<a href="#">Edit</a>
2	Polloy 2	On Sochedule	<a href="#">Edit</a>
⋮			
9	Polloy 9	On Sochedule	<a href="#">Edit</a>
10	Polloy 10	On Sochedule	<a href="#">Edit</a>

Please click **Edit** button to setting time policy rules.

**Time Policy Rules**

**Comment**

**Mode**  On Schedule  Out Of Schedule

---


**Policy List** [Create New Policy](#)

#	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Time	Action
-	-	-	-	-	-	-	-	-	-

- **Comment:** Enter the description of Time Policy rule. **There are maximum 10 for the time policy.**
- **Mode:** Administrator can select on schedule or Out of schedule to execution the rules.

### Create New Policy button:

Administrator can set time for week / start time and end time.



The screenshot shows a configuration window titled "Time Policy Rules". It contains a "Day of Week" section with checkboxes for Sun, Mon, Tue, Wed, Thu, and Fri, and a checkbox for Sat. Below this are "Start Time" and "End Time" sections, each with two dropdown menus. The Start Time dropdowns are set to "00" and the End Time dropdowns are set to "23" and "59".


Click "Save" button to add schedule to policy. **There are 300 schedule rules maximum allowed in the each time policy.** All schedules can be edited or removed in the each time policy. Click Reboot button to activate your changes.


## 6. Utility

### 6.1 Profile Setting

This Functions purpose is to backup current configuration, restore prior configuration or reset back to factory default configurations.

Please click on **Utility** -> **Profile Setting** and follow the below setting






- **Save Settings to PC:** Click **Save** button to save the current configuration to a local disk.
- **Load Settings from PC:** Click **Browse** button to locate a configuration file to restore, and then click **Upload** button to upload.
- **Reset To Factory Default:** Click **Default** button to reset back to the factory default settings and expect **Successful** loading message. Then, click **Reboot** button to activate.

## 6.2 System Upgrade

Firmware is the main software image that system needs to respond to requests and to manage real time operations. Firmware upgrades are sometimes required to include new features or bugs fix. It takes around 2 minutes to upgrade due to complexity of firmware. To upgrade system firmware, click Browse button to locate the new firmware, and then click Upgrade button to upgrade.



**Firmware Information:**

Display the system firmware information.

☰ Firmware Information

Sometimes it may be necessary to reboot the system if it begins working improperly. Rebooting the system will not delete any of your configuration settings. Click reboot button to reboot the system.

<b>Firmware Version</b>	<input type="text" value="Pme-CPE-IPQ60XX-CERIO V0.0.2"/>
<b>Firmware Date</b>	<input type="text" value="2024/05/06 12:45:19"/>

---

☰ Upgrade Via Local PC

<b>Select File</b>	<input type="button" value="Choose File"/> No file chosen	<input type="button" value="Upload"/>
--------------------	---	---------------------------------------

---

☰ Upgrade Via TFTP Server

<b>TFTP Server IP</b>	<input type="text"/>	
<b>File Name</b>	<input type="text"/>	<input type="button" value="Upload"/>

---

☰ Upgrade Via HTTP URL

<b>URL</b>	<input type="text"/>	<input type="button" value="Upload"/>
------------	----------------------	---------------------------------------

### Upgrade Via Local PC and TFTP Server:

The upgrade firmware will support via local PC and TFTP Server and HTTP URL to upgrade system.

- **Select File:** Administrator can select Firmware file in Local PC.
- **TFTP Server:** Enter IP address for TFTP Server.
- **File Name:** Enter file name.
- **URL:** Administrator can enter path for Firmware file.





Notice

1. To prevent data loss during firmware upgrade, please back up current settings before proceeding
2. Do not interrupt during firmware upgrade including power on/off as this may damage system.


## 6.3 Network Utility

The administrator can diagnose network connectivity via the PING or TRACEROUTE utility. Please click on **Utility -> Network Utility** and follow the below setting.



A screenshot of the 'Ping Utility' web interface. It features a title bar with a hamburger menu icon and the text 'Ping Utility'. Below the title bar, there are two input fields: 'IP/Domain' and 'Times'. The 'Times' field contains the number '5'. To the right of the 'Times' field is a green button labeled 'Ping'. Below the input fields is a large, empty rectangular area intended for the test results.

- **Ping** : This utility will help ping other devices on the network to verify connectivity. Ping utility, using ICMP packets, detects connectivity and latency between two network nodes. As result of that, packet loss and latency time are available in the **Result** field while running the PING test.
  - **IP/Domain:** Enter desired domain name, i.e. www.google.com, or IP address of the destination, and click ping button to proceed. The ping result will be shown in the Result field.
  - **Times:** By default, its 5 and the range is from 1 to 50. It indicates number of connectivity test.




The screenshot shows the 'Traceroute' utility interface. It has a title bar with a hamburger menu icon and the text 'Traceroute'. Below the title bar, there are two input fields. The first is labeled 'Destination Host' and has a green 'Start' button to its right. The second is labeled 'Max. Hops' and has the number '6' entered, with a green 'Stop' button to its right. Below these fields is a large, empty rectangular area for the test results.

- **Traceroute** : Allows tracing the hops from the DR-4000 device to a selected outgoing IP address. It should be used for the finding the route taken by ICMP packets across the network to the destination host. The test is started using the **Start** button, click **Stop** button to stopped test.
  - **Destination Host**: Specifies the Destination Host for the finding the route taken by ICMP packets across the network.
  - **MAX Hops**: Specifies the maximum number of hops (max time-to-live value) trace route will probe.

## 6.4 Log Maintenance

Administrator can monitor Log storage status for Session/Authentication and System. Please click on **Utility** ->**Log Maintenance** and follow the below setting.



Session Log Maintenance

**File Size/Peroent**

**Keep Date**

---

Authentication Log Maintenance

**File Size/Peroent**

**Keep Date**

---

System Log Maintenance

**File Size/Peroent**

**Keep Date**

- **File Size/Percent:** Display used volume and percentage.
- **Keep Date:** Display creation date.
  - **Delete button:** Administrator can click “delete” button to clear log information.

## 6.5 Reboot

This function allows user to restart system with existing or most current settings when changes are made. Click **Reboot** button to proceed and take around three minutes to complete.

Reboot

Sometimes It may be necessary to reboot the system If it begins working Improperly. Rebooting the system will not delete any of your oonfiguration settings. Click reboot button to reboot the system.

## 7. Status

### 7.1 Overview

Detailed information on System, Network can be reviewed via this page.

The screenshot shows two panels. The left panel, titled 'Overview', contains the following fields:

- Mode:** Router Mode (dropdown)
- System Name:** DR-4000
- System Time:** 2024/06/08 08:40:04
- System Uptime:** 52:23
- Firmware Version:** Pme-IPQ60xxR V0.0.2
- Firmware Date:** 2024/06/07 12:18:25
- ETH1 MAC Address:** 8c:4d:ea:05:2c:00
- ETH2 MAC Address:** 8c:4d:ea:05:2c:01
- Gateway:** 192.168.1.1
- DNS1:** 192.168.1.1
- DNS2:** (empty)

The right panel, titled 'Information', features six gauge charts:

- CPU Usage:** 0%
- Memory:** 17%
- Radius Log:** 0%
- Session Log:** 0%
- Authentication Log:** 0%
- System Log:** 0%

Below the gauges is a 'WAN0' section with:

- IP Address:** Dynamic IP (dropdown) | 192.168.1.106/24
- Received/Transmitted:** 13.490MB / 80.581MB

- **WAN#:** Display information for WAN Port setting. Administrator can click Action button to connect or disconnect for WAN Ports.

### 7.2 Local System Log

The system log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

The screenshot shows the 'System Log' interface with a table and two buttons: 'Refresh' (green) and 'Clear' (red).

Time	Facility	Severity	Message
-	-	-	-

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such “System” or “User”
- **Severity** : Severity level that a specific event is associated such as “info”, “error”, “warning”, etc.
- **Message** : Description of the event.
- Click “Refresh” button to renew the log
- Click “Clear” button to clear all the record.

## 7.3 Session Log

If enable “syslog server” in the “**Session Log**” (Hotspot Setup, Please refer to Chapter 3.4 ) and, the page can record account for session log. Session log page built-in smart-search function will display account use session information, administrator can use keyword or date approach to discover.

Session Log			
Name	Value		
Event Time	None	2016-11-21	2016-11-21
AP IP	None		
VLAN ID	None		
Username	None		
Protocol	None	TCP	
Source IP	None		
Destination IP	None		
Source Port	None		
Destination Port	None		
Source MAC	None		

Administrators can choose different data type in the search engines.

- **None:** The program doesn't judge characters, search all the information
- **Greater then:** Search values for greater than
- **Equal:** Search values for equal.
- **Less then:** Search values for less then.
- **Between:** Search values for between.
- **Like:** Search similar strings.

#	Event Time	AP IP	VLAN ID	Username	Protocol	Source IP	Destination IP	Source Port	Destination Port	Source MAC
1	2015-01-01 08:01:41	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	62461	1900	8C:4D:EA:02:C6:EC
2	2015-01-01 08:01:41	192.168.2.254	0	test	TCP	192.168.2.10	192.168.2.1	62362	443	8C:4D:EA:02:C6:EC
3	2015-01-01 08:01:42	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	59448	53	8C:4D:EA:02:C6:EC
4	2015-01-01 08:01:42	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	54064	53	8C:4D:EA:02:C6:EC
5	2015-01-01 08:01:42	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	53759	53	8C:4D:EA:02:C6:EC
6	2015-01-01 08:01:42	192.168.2.254	0	test	TCP	192.168.2.10	192.168.2.1	62364	443	8C:4D:EA:02:C6:EC
7	2015-01-01 08:01:44	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	62461	1900	8C:4D:EA:02:C6:EC
8	2015-01-01 08:01:46	192.168.2.254	0	test	TCP	192.168.2.10	192.168.2.1	62366	443	8C:4D:EA:02:C6:EC
9	2015-01-01 08:01:46	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	57436	53	8C:4D:EA:02:C6:EC
10	2015-01-01 08:01:46	192.168.2.254	0	test	TCP	192.168.2.10	192.168.2.1	62367	5222	8C:4D:EA:02:C6:EC
11	2015-01-01 08:01:47	192.168.2.254	0	test	UDP	192.168.2.10	192.168.2.1	62461	1900	8C:4D:EA:02:C6:EC
12	2015-01-01 08:01:48	192.168.2.254	0	test	TCP	192.168.2.10	192.168.2.1	62368	80	8C:4D:EA:02:C6:EC

If the session interception function setting used is not configured on the front-end Cerio AP on this machine, you can store the logs of the Cerio AP to this log server. Please enter the management settings of the Cerio AP and set the "Session Log" Setup points the IP to the device and enables the "session log" for the Cerio AP feature.

**# The following is a reference to the relevant settings of Cerio AP.**

**# Setup 1 :** Please click Cerio AP to "System" → "Authentication Setup" to enable to Session Log setting.

**Authentication Setup**

Multiple Login  3 User(s)

Login Timeout  Minutes

Redirect URL

Login URL

Authentication Log  Enable  Disable

Session Log  Enable  Disable

**# Setup 2 :** Please click Cerio AP to "Management" → "System Log Setup" to fill in remote Server IP Address.

System Log Setup

Remote Server  192.168.101.254

Port 514 Port

## 7.4 Authentication Log

If enable “syslog server” in the “Authentication Log” (Hotspot Setup, Please refer to Chapter 3.4 ) and authentication log in Cerio's AP, the page can record account for authentication log. Authentication log page built-in smart-search function will display account use session information, administrator can use keyword or date approach to discover.

Authentication Log

Name	Value
Event Time	None 2016-11-21 2016-11-21
AP IP	None
VLAN ID	None
Username	None
Source IP	None
Source MAC	None
Event	None

Administrators can choose different data type in the search engines.

- **None:** The program doesn't judge characters, search all the information
- **Greater then:** Search values for greater than
- **Equal:** Search values for equal.
- **Less then:** Search values for less then.
- **Between:** Search values for between.
- **Like:** Search similar strings.

Authentication Log List


#	Event Time	AP IP	VLAN ID	Username	User IP	User MAC	Event
1	2015-01-01 08:01:39	192.168.2.254	0	test	192.168.2.10	8c-4d-ea-02-c6-ec	LOGIN
2	2016-11-21 12:56:50	192.168.2.254	0	danny	192.168.2.10	8c-4d-ea-02-c6-ec	LOGIN
3	2016-11-21 12:57:28	192.168.2.254	0	danny	192.168.2.10	8c-4d-ea-02-c6-ec	LOGOUT
4	2016-11-21 12:57:37	192.168.2.254	0	test	192.168.2.10	8c-4d-ea-02-c6-ec	LOGIN
5	2016-11-21 13:02:22	192.168.2.254	0	danny	192.168.2.10	8c-4d-ea-02-c6-ec	LOGIN

If the authentication interception function setting used is not configured on the front-end Cerio

AP on this machine, you can store the logs of the Cerio AP to this log server. Please enter the management settings of the Cerio AP and set the "System Log" Setup points the IP to the device and enables the authentication log for the Cerio AP feature.

**# The following is a reference to the relevant settings of Cerio AP.**

**# Setup 1 :** Please click Cerio AP to "System" → "Authentication Setup" to enable for Authentication Log setting.



Authentication Setup

Multiple Login  3 User(s)

Login Timeout 10 Minutes


Redirect URL http://www.google.com

Login URL domain0.login

Authentication Log  Enable  Disable

Session Log  Enable  Disable

**# Setup 2 :** Please click Cerio AP to "Management" → "System Log Setup" to fill in remote Server IP Address.



System Log Setup

Remote Server  192.168.101.254

Port 514 Port

## 7.5 Remote System Log

If enable "syslog server" in the "Remote System Log" and Remote System log in Cerio's AP, The page can record Remote system log for Cerio Aps too.

**System Log**

Name	Value		
Event Time	None	2016-11-21	2016-11-21
Device IP	None		
Facility	None	Kernel messages	
Priority	None	Emergency	
Message	None		

Administrators can choose different data type in the search engines.

- **None:** The program doesn't judge characters, search all the information
- **Greater then:** Search values for greater than
- **Equal:** Search values for equal.
- **Less then:** Search values for less then.
- **Between:** Search values for between.
- **Like:** Search similar strings.

**System Log List**

#	Event Time	AP IP	Facility	Priority	Message
1	2016-01-01 08:00:00	192.168.2.254	user	Informational	PPP BSD Compression module registered
2	2016-01-01 08:00:00	192.168.2.254	user	Informational	PPP MPPE Compression module registered
3	2016-01-01 08:00:00	192.168.2.254	user	Informational	NET: Registered protocol family 24
4	2016-01-01 08:00:00	192.168.2.254	local0	Informational	started, version 2.22 cachesize 150
5	2016-01-01 08:00:00	192.168.2.254	local0	Informational	cleared cache
6	2016-01-01 08:00:00	192.168.2.254	local0	Informational	reading /etc/resolv.conf
7	2016-01-01 08:00:00	192.168.2.254	local0	Informational	using nameserver 192.168.2.1#53
8	2016-01-01 08:00:00	192.168.2.254	user	Informational	PPPoL2TP kernel driver, V1.0

If the remote system interception function setting used is not configured on the front-end Cerio AP on this machine, you can store the logs of the Cerio AP to this log server. Please enter the management settings of the Cerio AP and set the "System Log" Setup points the IP to the device for the Cerio AP feature.

**# The following is a reference to the relevant settings of Cerio AP.**

**# Setup 1 :** Please click Cerio AP to "Management" → "System Log Setup" to fill in remote Server IP Address.

**System Log Setup**


**Remote Server**  192.168.101.254

**Port** 514 Port

## 8. Technical documents

### 8.1 Example for PPTP/L2TP setup

Create a VPN tunnel use server / client bridge for the PPTP / L2TP protocol, if PPTP server set virtual IP address is 10.10.10.1 then must also set start to end IP address for dynamic configuration, can give VPN client automatically obtain a virtual IP address. The following concept map



#### PPTP Server setup step

1. Enable PPTP/L2TP Server and set VPN used virtual IP address. (Refer to 3.6 /3.7 for instructions)

**PPTP Server Settings**

<b>Connections</b>	<input type="text" value="3"/>
<b>Local IP Address</b>	<input type="text" value="10.10.10.1"/>
<b>Remote Start IP Address</b>	<input type="text" value="10.10.10.10"/>
<b>Remote End IP Address</b>	<input type="text" value="10.10.10.13"/>
<b>MPPE40</b>	<input checked="" type="radio"/> <b>Enable</b> <input type="radio"/> <b>Disable</b>
<b>MPPE128</b>	<input checked="" type="radio"/> <b>Enable</b> <input type="radio"/> <b>Disable</b>

2. Create authentication of client account and password

**Account Setup**

<b>User Name</b>	<input type="text" value="danny"/>
<b>Password</b>	<input type="password" value="....."/>
<b>PPTP Support</b>	<input checked="" type="radio"/> <b>Enable</b> <input type="radio"/> <b>Disable</b>
<b>L2TP Support</b>	<input checked="" type="radio"/> <b>Enable</b> <input type="radio"/> <b>Disable</b>

Setup routing between the two networks

**Routing Rule**

<b>Local Subnet</b>	<input type="text" value="192.168.2.0/24"/>
<b>Remote Subnet</b>	<input type="text" value="192.168.3.0/24"/> <input type="button" value="Add"/>

## PPTP Client setup step

1. Set real IP address of remote VPN server and authentication account / password.

☰ PPTP/L2TP Client Setup

Active     Enable     Disable

---

☰ PPTP/L2TP Client Settings

Mode     PPTP     L2TP

Server IP Address

User Name

Password

---

☰ PPTP Setup

MPPE40     Enable     Disable

MPPE128     Enable     Disable

## 2. Setup routing between the two networks

☰ Routing Rule List

#	Local Subnet	Remote Subnet	Action
1	192.168.3.0/24	192.168.2.0/24	<span style="background-color: #d9534f; color: white; padding: 2px 5px; border-radius: 3px;">Delete</span>

When the setting is complete, the both of the network will be through the VPN tunnel for data transmission.

Administrator can track the discovery, both network is used VPN tunnel to transmission.

```

Tracing route to 192.168.2.10 over a maximum of 30 hops
  0  <1 ms  <1 ms  <1 ms  192.168.3.1
  1  10 ms   9 ms   9 ms  10.10.10.1
  2  10 ms   9 ms   9 ms  192.168.2.10
Trace complete.
```


## 8.2 Hotspot function used POS system application




Cerio's POS system device by optional.

POS system is authentication device of the special use network control server (SP-800) + Thermal printer. You can refer to SP-800-PRINTER and SP-800-QRCPT for Cerio's . Administrator can use SP-800 to generate a new account for the remote control Cerio's Web authentication device and print authentication account.

### Cerio's controller mounted SP-800-PRINTER for POS system application diagram




### Cerio's controller mounted SP-800-QRCPT for POS system application diagram.



## Login management interface for SP-800

Network control server(SP-800) built-in web management interface. After install POS system architecture, administrator can use network connect to SP-800 interface and management. The SP-800 manager URL is <http://192.168.2.253/setting.htm>, please open IE or Firefox browser and enter URL address to set function.



**CERIO** Network Control Server v1.1

**COM1 Settings**

Data Baud Rate: 9600

Data Bits: 8

Data Parity: None

Stop Bits: 1

Flow Control: None

**Network Settings**

Enable DHCP

Static IP Address: 192.168.2.253

Static Subnet Mask: 255.255.255.0

Static Default Gateway: 192.168.2.254

Static DNS Server: 168.95.1.1

Transmit Timer: 10

**Server:**

Server Listening Port: 5000

Apply Reset

Firmware Upgrade

- **COM1 Setting:** Recommend use default ◦
- **Network Setting:**
  - **Enable DHCP:** Administrator can select enable or disable DHCP client.
  - **Static IP Address:** Administrator can set IP address for SP-800.
  - **Static DNS Server:** Administrator can set IP address for DNS server. ◦
  - **Transmit Timer:** system to detect controller connect status (millisecond).
  - **Server Listening Port:** SP-800 connection to controller use Port. (SP-800 and controller must be set the same port).

After setting is complete, please click Apply button.

## Install normal thermal printer

### # Install step for thermal paper


- 1) Open the cover for thermal printer
- 2) Place the thermal paper in the printer groove
- 3) After pull the paper out a small portion please close the lid for thermal printer




- 1) SP-800 connection to thermal printer use console port
- 2) DC Power in.
- 3) Power on/off switch.

## Install QR Code thermal printer

Behind the printer connection functions support USB / console / RJ-45 /RJ-11 and Power.  
As follows



PS. Connect the controller only need to use RJ-45 and power.




### # Login web page for QR Code printer.

The QR Code printer support web management interface, administrator can login web page and modify IP address for the QR Code printer.


QR Code Printer default IP address: **192.168.123.100**

As follows




## # Install or Replace Paper Roll for QR code printer

- 1) Pull the Cover Release Button to open the Cover.




- 2) Roll out and install the Paper Roll with Holder into the Printer. (with the edges of the paper roll holder fitted onto the holder slots)



3) Please close the lid for thermal printer.

## # DIP Switch Setting for QR code Printer

DIP Switch in printer bottom.



DIP	Function	ON	OFF
1	Paper Cutter	No	Yes*
2	Audio Alarm	Yes *	No
3	Print Density	Dark	Light *
4	Two-byte Character Code	*No	Yes
5	Character Per Line	42	48 *
6	Cutter with Cash Drawer	Yes	No *
7 & 8	Baud Rate Setting	---	OFF*

### # Baud Rate Setting (DIP 7, DIP 8)



## Set web authentication steps for POS system

Cerio's Web Authentication System consists of the controller and SP-800 + Printer; administrator can use SP-800 remote control Cerio's controller to create an account and print out.

The architecture can refer to "POS system application" description

### Set web authentication steps, as follows

(Take Cerio's DR-4000 as the case)

#### Steps1

Login SP-800 web interface to set IP address and set same network segment

You can refer to "Login management interface for SP-800"

#### Steps2


If SP-800 with QR code Printer, administrator must set IP address for QR code Printer (same network segment for your network). You can refer to "Install QR Code printer"

#### Steps3

Login Cerio's Controller "DR-4000" page (Refer controller user manual) to enable RADIUS Server.

As follows

Please click menu "Account" → "RADIUS Server" for Cerio's DR-4000



Service	<input checked="" type="radio"/> Enable	<input type="radio"/> Disable
Authentioation Port	<input type="text" value="1812"/>	
Aooounting Port	<input type="text" value="1813"/>	
Radius Seoret	<input type="text" value="(4-32 chars)"/>	

## Steps4

Set the connection between **DR-4000** and SP-800. Please click menu **“Account”→“Thermal Printer Setup”** to enable function, as follows

Thermal Printer List					
Printer#	Service	IP Address	Description	Balance Time	Action
1		192.168.2.253		00:00	<a href="#">Setup</a>
2				00:00	<a href="#">Setup</a>
3				00:00	<a href="#">Setup</a>
4				00:00	<a href="#">Setup</a>
5				00:00	<a href="#">Setup</a>

Printer Setup

Service  Enable  Disable

Printer Setup

IP Address:

Command Port:

Printer Type:

COM Port:

New Look Password:

Description:

Balance Time:

- **IP address:** Please enter IP address for SP-800 (You can refer to Login SP-800)
- **Command port:** Please enter Command for SP-800 (You can refer to Login SP-800)
- **Printer Type:** Administrator can select Printer for normal or QR Code Printer.
- **QR code Printer :** If select QR Code printer, administrator must choose use connection for IP address or com Port.(Recommend use IP address manner.)

Printer Type:

COM Port:

Printer IP Address:

Printer Port:

QRCode Type:

- ✓ **Printer IP Address** : Please enter IP address for QR code printer. (You can refer to Install QR Code Printer).
- ✓ **Printer Port** : Please enter command port for QR Code Printer. (You can refer to Install QR Code Printer)
- ✓ **QR Code Type** : Administrator can select print out size for QR code.
- **COM Port:** Please select connection type for printer.




1. If use normal thermal printer and connect to com1 port of the SP-800, please select **COM1**
2. If use QR Code Printer, please select **RJ-45**

- **New Lock Password** : Enter pass key of the **DR-4000** to connect SP-800
- **Description** : Administrator can enter description.

## Steps5

Setup internet time rules for package authentication type (**DR-4000**). Please click menu “Account” → “Package setup”. As follows



The screenshot shows a 'Package Setup' form with the following fields:

- Package Name**: Text input field with a placeholder '(4-32 chars)'
- Description**: Text input field with a placeholder '(4-64 chars)'
- Traffic Volume**: Text input field with a unit selector 'MB'
- Session Time**: Text input field with a unit selector 'Minutes'
- Expire After**: Text input field with a unit selector 'Minutes'
- Expiration**: Dropdown menu with 'Unlimited' selected

- **Package Name:** Administrator can set Identify name for the package rules.
- **Description:** Administrator can set the description for package rules.
- **Traffic Volume:** Administrator can set authentication account use traffic limit for the package rules.
- **Session Time:** Administrator can set authentication account use session limit for the package rules. (After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in. )
- **Expire After:** Administrator can set authentication account use how many hours expire.( After the account is signed in, the system start counted time until the end time.)

➤ **Expiration:** Administrator can select Unlimited or Per Day or Until Time.

- ✓ **Unlimited:** After the account is signed in, the system does not count the time
- ✓ **Per Day:** After the account is signed in, the system start counted time until the end time.
- ✓ **Until Time:** After the account is signed in, the system will begin counting until the set time is used up. The counting will stop when users log out, and begin counting again once the user signs back in.


PS. Package list (0~9) is Network control server (SP-800) code, administrator can choose number to print out account.

Package List							Create New Package
#	Name	Description	Session Time	Traffic Volume	Expire After	Expiration	Action
0	TEST-1	no time		0B			Edit
1	test-2	60Mbps Trafflo		60.00MB			Edit
2	test-3	use 120 minutes time	2Hour(s)	0B			Edit
3	Test-4	use 120 minutes expl...		0B	2Hour(s)		Edit

## Steps6

The system time is very important, administrator must set system time is right. Please click **DR-4000** menu “**System**” → “**Time Server**” to set system time.

PS. Recommend select update the system time for the NTP Server



The screenshot shows the 'System Time' configuration page. It features a 'Local Time' field displaying '2016/12/02 13:42:09'. Below this, there is a 'Mode' section with two radio buttons: 'NTP Server' (which is selected) and 'Manual'.

The above procedure will complete the **DR-4000** setting

## # Enable Web authentication for Access Point


Hot spots web authentication architecture must be with combine Cerio's CenOS5.0 access point.

As follows

## Steps7


Enable Web authentication for Cerio's CenOS5.0 Access Point. (You can refer user manual for Access Point), As follows for Cerio's Access Point.

1) Enables web authentication function. Please click “System” → “Authentication” for Cerio's Access Point.



#	VLAN Mode	Authentication	Action
0	On	Off	Authentication
1	Off	Off	Authentication
2	Off	Off	Authentication
3	Off	Off	Authentication
4	Off	Off	Authentication
5	Off	Off	Authentication

2) Click Authentication button and enable the function.



The screenshot shows the 'Authentication' configuration page. It features a section with the label 'Authentication' and two radio buttons: 'Enable' (which is selected) and 'Disable'.

3) Enable authentication for RADIUS Server and set IP address for **DR-4000**.

The screenshot shows the 'Radius Setup' configuration page. It includes the following fields and options:

- Radius:** Radio buttons for  Enable and  Disable.
- Display Name:** Text input field containing 'Radius User'.
- Primary Server IP:** Text input field containing '192.168.2.1'.
- Secondary Server IP:** Text input field containing 'Options'.
- Authentication Port:** Text input field containing '1812' with a 'Port' button.
- Accounting Service:** A checked checkbox next to '1813' with a 'Port' button.
- Authentication Type:** Radio buttons for  PAP and  CHAP.
- Secret Key:** Password input field with masked characters '.....'.

### Steps8

Set system time for Cerio's Access Point. Please click menu "System" → "Time server".

### Steps9

The system time is very important, administrator must set system time is right. Please click menu "System" → "Time Server" to set system time.

The screenshot shows the 'System Time' configuration page. It includes the following fields and options:

- Local Time:** Text input field showing '2016/12/02 13:42:09'.
- Mode:** Radio buttons for  NTP Server and  Manual.

This completes all architecture settings

Administrator can click SP-800 "Print" button will print account and password of the tickets.

As follows

